


2.60 HL SST

Automotive-Lift date: 01/2010
Manual date: 15.03.2012



Original Documentation

Operating instructions and documentation

Serial-number:.....

Retailer address / phone

Made in Germany



Nussbaum

Otto Nußbaum GmbH & Co.KG//Korker Straße 24D-77694 Kehl-Bodersweier
Tel: +49(0)7853/8990 Fax: +49(0)7853/8787
E-mail: info@nussbaum-lifts.de// http://www.nussbaum-lifts.de

Contents

Foreword	3
Record of installation	5
Record of handing over	6
1.General Information.....	7
1.1 Installation and service checks of the automotive lift	7
1.2 Warning Symbols	7
2.Master document of the automotive lift.....	8
2.1 Lift–manufacturer.....	8
2.2 Application	8
2.3 Changes to the Lift Construction	8
2.4 Displacement of the automotive-lift.....	8
2.5 Declaration of conformity	9
3. Technical Information	10
3.1 Technical ratings	10
3.2 Safety device	10
3.3 Data sheet	11
4.Safety regulations	15
5.Operating Instructions.....	16
5.1 Lifting the vehicle	16
5.2 Lowering the vehicle	17
5.3 Position measurement	17
5.4 Manual equalization of the automotive lift.....	17
6.Troubleshooting	18
6.1 Lowering onto an obstacle.....	19
6.1.1 Remove an obstacle	19
6.2 Emergency lowering	20
6.2.1 Emergency lowering procedure	21
6.3 Reset after an emergency lowering	22
7.Inspection and Maintenance	23
7.1 Maintenance plan of the lift.....	23
7.2 How often must the lift be cleaned?.....	25
8. Security check	26
9. Handing over and Initiation	26
9.1 Regulations.....	26
9.2 Erection and bolting down the lift	27
9.3 Initiation	27
9.4 Change of lift location	28
First security check before installation	33
Regular security check and Maintenance	35
Extraordinary security check.....	43
Hydraulic diagram drawing	44
Electrical diagram drawing.....	46

Foreword

Nußbaum lifting systems are the result of a long time experience in the automotive lifting industry. The high quality and the superior concept ensure reliability, a long lift lifetime and above all an economic business solution.

To avoid unnecessary damage, injury or even death, read the operating instructions with care and observe the contents.

Nußbaum lifts is not responsible for incidents involving the use of Nußbaum lifting systems for applications other than those for which they were designed.

Otto Nußbaum GmbH & Co. KG is not liable for any resulting damages. The user carries the risk alone.

Obligations of the user:

- To observe and adhere to the operating instructions.
- To follow the recommended inspection and maintenance procedures and carry out the prescribed tests.
- The operating instructions must be observed by all persons working with or around the lift.
- Above all chapter 4 "Safety Regulations" is very important and must be closely adhered to.
- In addition to the safety regulations stated in the operating instructions manual, the appropriate safety regulations and the operating procedures of the place of operation must also be considered.

Obligations of the operator:

The operator is obliged to allow only those persons complying to the following requirements to work with or around the unit.

- Persons being familiar with the basic regulations concerning labour safety and accident prevention and being trained to operate the particular unit.
- Persons having read and understood the chapter concerning safety and warning symbols.
- Persons using the lift are required to confirm that they have read and understood the chapter on safety and warning symbols by signing the appropriate form.

Dangers when operating the lift:

Nußbaum-Lifts are designed and built according to technical standards and the approved regulations for technical safety. The use of Nußbaum lifts for purposes other than those for which they were designed, may result in injury or even death.

The lift must only be operated :

- For its appropriate use
- In faultless condition concerning technical security.

Organisational Requirements

- The instructions for use are to be kept at the place of operation being easily accessible at any time.
- In addition to the instructions for use, rules pertaining to other regulations i.e. accident prevention and environmental rules are to be observed and adhered to.
- The owner of the Nußbaum lifting system must ensure that operators and persons working with or around the lift occasionally conduct "refresher" courses to ensure that the appropriate operating procedures and safety precautions are known.
- Personal Protective Equipment (PPE) must be used according to the appropriate regulations.
- All safety- and danger signs on and around the lift are to be observed and followed!
- Spare parts must comply with the technical requirements specified by the manufacturer.
This is only warranted with original parts.
- Observe and adhere to the specified time intervals between tests and inspections.

Maintenance works, repairing faults

- Adjustments, maintenance, and inspections, are to be followed according to the time intervals specified. Details regarding the exchange of parts and components as mentioned in the operating instructions are to be adhered to.
These works must only be carried out by expert personal.
- After maintenance- and repair works loose screws, nuts and bolts must always be firmly tightened!

Guarantee and liability

- Our "General conditions of selling and delivering" are in force.
There will be no guarantee or liability for incidents involving injuries or death or damage to equipment if these incidents are the result of one or more of the following reasons.
- Inappropriate use of the lift
- Inappropriate installation, initiation, operation and maintenance of the lift.
- Use of the lift while one or several security devices do not work, do not work correctly or are not installed correctly.
- Failure to follow the regulations of the operating instructions regarding transport, storage, installation, initiation, operation and maintenance of the lift.
- Unauthorized changes to the structure of the lift without first asking the producer.
- Unauthorized changes of adjustments of important components of the lift (e.g. driving elements, power rating, motor speed, etc)
- Wrong or incorrect maintenance practice.
- Catastrophes, acts of God or external reasons.



After completely filling out this sheet including signatures, copy and return the original to the manufacturer. The copy must remain in the manual.

**Otto Nußbaum GmbH & Co. KG
Korker Straße 24
D-77694 Kehl-Bodersweier**

Record of installation

The automotive lift with the

serial number:..... was installed on:.....

at the firm:..... at:.....

The initial safety check was carried out and the lift was started.

The installation was carried out by the operating authority/competent (please delete as applicable).

The initial safety check was carried out by a competent person before the initial operation.

The operating authority confirms the correct installation of the automotive lift, the competent person confirms the correct initial operation.

Used Dowels(*):_____ (Type/Name)

Minimum anchorage depth (*) kept: _____ mm ok

Starting torque (*) kept: _____ NM ok

..... date name of the operating authority signature of the operating authority

..... date name of the competent person signature of the competent person

Your customer service:..... (stamp)

(*) see supplement of the dowel manufacturers

Automotive Lift date: 01/2010 / Manual date: 15.03.2012

Record of handing over

The automotive lift with the

serial number:..... was installed on:.....

at the firm:..... at:.....

the safety was checked and the lift was started.

The persons below were introduced after the installation of the automotive lift. The introduction was carried out by either the erector from the lift-manufacturer or from a franchised dealer (competent person).

..... date name signature

..... date name of competent signature of the competent

Your customer service:.....(stamp)

1.General Information

The document “**Operating Instructions and Documentation**” contains important information about installation, operation and maintenance of the automotive lift.

- Conformation of **installation of the automotive lift** is recorded on the "Record of Installation" form and must be signed and returned to the manufacturer.
- Conformation of once of, regular and out of the ordinary service checks is recorded in the respective check forms. The forms are used to document the checks. They should not be removed from the manual.

All **Changes to the structure** and any change of **location** of the automotive lift must be registered in the "**Master document**" of the lift

1.1 Installation and service checks of the automotive lift

Only specialised staff are allowed to repair and maintain the lift and only these specialised staff are allowed to conduct safety checks on the lift. For the purposes of this document these specialised staff will be called Experts and Competent persons.

Experts are persons (for example self-employed engineers, experts) which have received instructions and have the appropriate experience to check and to test the automotive lifts. They are aware of the work involved and know the accident prevention regulations.

Competent persons are persons who have acquired adequate knowledge and experience with automotive lifts. They have completed the appropriate training provided by the lift-manufacturer (the servicing technicians of the manufacturer or dealer, are regarded as competent)

1.2 Warning Symbols

The three symbols below are used to indicate danger and other important information. Pay attention to areas on and around the lift that are marked with these symbols.



Danger! This sign indicates danger. Ignoring this warning may result in injury or even death.



Caution! This sign cautions against possible damage to the automotive lift or other material objects in the case of improper use .



Attention! This sign indicates an important function or other important information regarding the operation of the lift.

2.Master document of the automotive lift

2.1 Lift–manufacturer

Otto Nußbaum GmbH & Co. KG
Korker Straße 24
D-77694 Kehl-Bodersweier

2.2 Application

The automotive lift HL is a lifting mechanism for lifting motor vehicles with a laden weight of up to 6000 kg . The max. load distribution is 3:1 either in or against the drive-on direction.

The capacity is reduced to max. 4200 kg when using the forklift adapters.

The automotive lift has been designed for servicing vehicles only. It has not been designed to carry people. Carrying people either directly on the lift or in vehicles that are on the lift is therefore not allowed.

The installation of the standard lift in hazardous or dangerous locations such as wash bays is dangerous and is therefore not allowed.

2.3 Changes to the Lift Construction

Changes to the construction, expert checking, resumption of work (date, type of change, signature of the expert)

.....
.....
.....
.....
name, address of the expert

.....
place, date

.....
signature of the expert

2.4 Displacement of the automotive-lift

Displacement of the automotive-lift, expert checking, resumption of work (date, kind of change, signature of the competent)

.....
.....
.....
.....
name, address of the competent

.....
place, date

.....
signature of the competent

2.5 Declaration of conformity**EG- Konformitätserklärung****Nussbaum****gemäß Maschinenrichtlinie Anhang II 1A**

Declaration of Conformity according Machinery Directive 2006/42/EG ANNEX II 1A
Déclaration de conformité selon directive machines annexe II 1A
Declaración de conformidad según Directiva Maquinaria 2006/42/EG ANNEX II 1A
Dichiarazione di conformità in accordo alla direttiva 2006/42/EG ANNEX II 1A

Hiermit erklären wir, daß die Hebebühne, Modell:

Hereby we declare that the lift model:

Par la présente nous déclarons que le pont élévateur modèle:

Por la presente declara, que el elevador modelo:

Con la presente si dichiara che il sollevatore:

HL 2.60 SST DG**2.60 HL SST DG****allen einschlägigen Bestimmungen der folgenden Richtlinien entspricht:**

fulfills all the relevant provisions of the following Directives:

correspond aux normes suivantes:

cumple todas las disposiciones pertinentes de las Directivas siguientes:

adempie a tutte le richieste delle seguenti direttive:

**Maschinenrichtlinie / Machinery Directive
EMV Richtlinie / EMC Directive**2006/42/EG
2004/108/EG**in Übereinstimmung mit den folgenden harmonisierten Normen gefertigt wurde**
was manufactured in conformity with the harmonized norms

fabriqué en conformité selon les normes harmonisées en vigueur.

producido de acuerdo a las siguientes normas armonizadas.

è stato fabbricato in conformità con le norme armonizzate

**Fahrzeug- Hebebühnen / Vehicle lifts
Elektromagnetische Verträglichkeit / Electromagnetic compatibility (EMC)**EN 1493: 2010
EN 61000-6-2 , -6-4**Beauftragter für die Technische Dokumentation**
Authorised to compile the technical file**M. Golutzki (Nussbaum)****Seriennummer**
Serial number**Seriennummer****Konformitätserklärung gültig bis / Declaration of Conformity valid until:****31.12.2011****Kehl- Bodersweier, 31.10.2011**

Otto Nußbaum GmbH & Co. KG
Korker Straße 24
77694 Kehl-Bodersweier
Tel.: 0 7853/899-0
i.A. Thomas Hassler (CE)

NussbaumOtto Nußbaum GmbH & Co. KG · Korker Str. 24 · D-77694 Kehl-Bodersweier
Tel.: +49(0)7853/899-0 · Fax: +49(0)7853/8787 · www.nussbaum-lifts.de

3. Technical Information

3.1 Technical ratings

Capacity	6000 kg
Load distribution	max. 3:1 in or against the drive on direction
Lifting time	approx. 78 sec. with 5900 kg Load
Lowering time	approx. 65 sec. with CE-Stop and 5900 kg Load
Line voltage	3 x 400 Volt , 50Hz
Power rating	1.5 kW (992463)
Motor speed	1400 rotation/min
Pump capacity	5,7 cm ³ (Marz.) 1BK7S9,2Q
Hydraulic pressure	approx. 205 bar
Pressure control valve	approx. 215 bar
Hydraulic pressure (SST System)	approx. 35 bar
Oil tank	per Hydraulic unit approx. 17 Litre
Sound level L _{pA}	≤ 70 dB
Connection by customer	3~/N+PE, 400V, 50 Hz fuse 16 Ampere (time-lag fuse) observe your state regulations

3.2 Safety device

1. Pressure relief valve
Protects the hydraulic system from exceedingly high pressures.
2. Holding valve (check valve)
Safety device against unintentional lowering
3. Lockable main switch
Safety device against unauthorised operation
4. CE-Stop + acoustic signal (Optional)
Safety device to avoid crushing (e.g. foot in lift recess)
5. Hydraulic unlocking safety system at the cylinder.
Safety device against unintentional lowering
6. Pneumatic lockable arm
Protection against unintentional adjusting of the arms
7. Foot-protection at the standard arms
Safety device to avoid crushing

3.3 Data sheet

Bauseite ist auf der Bodensäule bereitgestellt:
 Absicherung: 16 Ampere träge.
 für optionales Energieset:
 Druckluft: Lüftleit 6mm, 6-10 bar
 prepared by customer at the operating column:
 power supply: 3PH+NPE, 400V, 50Hz
 16 Ampere time lag.
 optional Energy set:
 Air pressure: 6mm diameter, 6-10bar
 observe the lower supply of your country


This technical drawing illustrates the dimensions and components of a control column assembly. The overall width is 4640-max. 5090 mm, and the maximum height is 3980 mm. The distance between the top of the operating column and the floor is 2810 mm. The operating column itself has a height of 1980 mm. The distance from the floor to the top of the air pressure cylinder is 105180 mm. The total height of the assembly is 1105 mm. A callout indicates that the power supply (PS) is guided through the operating column from above. Another callout specifies that compressed air pressure is supplied from above into the cylinder. The drawing also shows a vertical dimension of 35 mm on the left side.

Betonqualität quality of concrete min. C20/25 normal normal armouring	Betondicke ohne Bodenholz without floor pavement (Stahlbewehrung) mm. 250 mm
---	--

Wir weisen in unseren Plänen auf die Mindestanforderung des Fundamentes hin. Je nach der Zustand der örtlichen Gegebenheiten (z. B. Untergrund etc.) darf es nicht unserer Verantwortung. Die Einbausitzung muss vom Planenden Architekten bzw. Statiker im speziellen Fall individuell spezifiziert werden.

We point out the minimum requirements of the foundation in our plans. The condition of the local realities (e.g.: ground under the foundation etc.) does not lie in our responsibility. If necessary an architect must be consulted.

All measurements in millimeter
all measures in millimeter
subject to alterations!
Mass- und Konstruktionsänderungen vorbehalten!



Die Mindestverankerungstiefe des Dübelns beachten. Mit Estrich/Fliesen sind längere Dübeln einzusetzen.

Observe the min. anchorage of the dowels. With floor movements use inner dowels

Die Meistsecoverbeschaffung ist eine der wichtigsten Maßnahmen zur Kostenkontrolle.

Observe a regular rotation of the dome of manufacture.

Massstab: **Gewicht:**

Werkstoff / Material

卷之三

Benennung

SST
H
60
n
.

mit Donner | ne | enk | ronnen

mit Doppelgelenktragarmen

with double joint arms

Blatt

691/-4-EINBAU

Ersatz fuer: _____ Ersatz durch: _____

卷之三

卷之三

Zeichnungsnr. 6917-4_E INBAU
With double joint arms
Ersatz Ler.: Ersatz durch:

This technical cross-section diagram illustrates the foundation and pier structure of a bridge. The vertical axis shows the following dimensions from bottom to top:

- Pier height: Fundament 4300
- Distance from pier base to concrete slab: 495
- Distance from pier base to ground level: max 1890
- Distance from pier base to ground level at the top of the pier: 850
- Total height above ground level: Fundament 1650

The horizontal distance from the pier center to the outer edge of the foundation is indicated as 2500. The diagram also shows the thickness of the concrete slab as 400 mm and the thickness of the pavement as 230 mm. A note specifies "Boden bei Log-seen) min. 250mm".

Construction details include a "Drahtförmiger Anker" (wireform anchor) at the top of the pier and "Drähte in der Füllung" (wires in the filling) in the foundation. The diagram also shows the "Z" axis.

cause it to generate power (Strom, Luft) von den Bedienelementen einführen
guide the power supply (electric, air pressure) vom oben nach unten

Betonqualität quality of concrete	Betonstruktur ohne Bewehrung (E-Strich/F-Resen) min 250mm
norm C20/25	Thickness of the concrete
norm. bewehrt normal armoured	without floor pavement, min 250mm
	at 1st floor height (C16/20)

Wir weisen in unseren Plänen auf die Mindestanforderung des Fundamentes hin, jedoch der Zustand der artlichen Gegebenheiten (z.B. Untergrund etc.) sollte nicht unserer Verantwortung. Die Einbaulösung der Einbaustützen muss vom Planenden Architekten bzw. Statiker im speziellen Fall individuell spezifiziert werden.

Alle Massen in Millimeter
all measure in millimeter
subject to alterations!
Mass- und Konstruktionsänderungen vorbehaltlich!

Tragfähigkeit:


The diagram illustrates a bridge section with various dimensions and components:

- max. Höhe Hubsechtlüttchen 3980**: Maximum height of the hub section.
- 2736**: Width of the main bridge structure.
- 2810**: Total width of the bridge including side wings.
- max 1980**: Maximum height of the operating column.
- 105-180**: Height of the base structure.
- Bediensäule operating column**: Label for the vertical support column.
- DKFB**: Label for a structural element on the right side.

The diagram illustrates a conveyor system with the following dimensions:

- Overall width:** Fundament Breite 3500 mm
- Conveyor width:** Durchfahrtsbreite 2510 mm
- Vertical height:** max. 4210 mm
- Vertical height at the top:** max. 2510 mm
- Vertical height of the drive unit:** 425 mm
- Vertical height of the frame:** 495 mm
- Vertical height of the support legs:** max. 1890 mm
- Horizontal distance from the front leg to the rear leg:** Fundament Breite 1650 mm
- Vertical distance between the top of the frame and the top of the support legs:** 650 mm
- Vertical distance between the top of the frame and the top of the drive unit:** 750 mm
- Length of the conveyor belt:** 4300 mm
- Labeling:** Einförderfachung (drive unit), Drive on direct connection


Detail "Z"
Grundplatte
base plate




Die Montagevorschrift des Dabe Herstellers beachten.
Observe the regulation of the dabe manufacturer

Passform	Toleranzgraben	Maßstab	Verkstoff / Holzart	gewicht:		
		Datum	None	- j -		
		Bearb.	09.12.09	M.G.	Bemerkung	2.60 HL SST
		Gef.				mit Leerrohr unterlief
		Norm				
					Zeichnungsnr.	6917-9_EINBAU
						Blatt
					Ersatz für:	
						Von
						Ersatz durch:

Bosch Itig on der Bedienstühle bereitstellen:
 Netzzuschluss: 3Ph. NPE. 400V. 50Hz
 Absicherung: 16 Amperes trage.
 für optionales Energieset:
 Druckluft: lichtweite 6mm. 6-10 bar
 prepared by customer of the operating column:
 power supply: 3Ph. NPE. 400V. 50Hz
 fuse: 16 Amperes time lag
 optional Energy set:
 Air pressure: 6mm diameter. 6-10bar
 observe the power supply of your country



Bauseitig an der Bedieneule bereitstellen:
Nur Zerschlag: 3PH+NPE, 400V, 50Hz
Absicherung: 16 Amperre troge
 für opt. ionales Energieset:
Druckluft: 1 lichte Weite 6mm, 6-10 bar
 reported by customer at the operating column:
power supply: 3PH+NPE, 400V, 50Hz
optional: Amperre troge
Air pressure: 6mm diameter, 6-10bar
 observe the power supply of your country




The diagram shows a vertical rectangular column representing a power supply unit. A horizontal dimension line at the bottom indicates a width of 95 mm. To the left of the column, there is a legend box containing German text and symbols:

- bauseitige Versorgungsleitung
(Strom Luft) von oben
- In die Bediensäule einführen
- gibt die power supply
the power supply
(electric, air pressure)
- from above into the
column


The diagram shows a cross-section of a concrete foundation wall. At the top, a horizontal beam is supported by two vertical columns. The wall itself is made of concrete with a thickness of 250 mm. A layer of mortar (Estrich/Füllersen) is applied to the top surface, with a minimum thickness of 20 mm. Below the wall, there is a layer of sand (Bodenlage) with a minimum thickness of 200 mm. The total height of the wall section is 215 mm. On the left side, a vertical dimension of 270 mm is indicated. On the right side, there is a legend with the following information:

- Betonstärke ohne (Estrich/Füllersen) min. 250 mm
- Thickness of the concrete without floor paving, ct l. 250 mm
- Betonqualität quality of concrete
- min. C20/25
- normal armuring
- max. 2015


Capacity: 6000kg



Die Mindestverankerungslänge des Döbel's beachten.
Bei Estrichfliesen sind längere Döbel einzusetzen.
Um die Min. Anchurage of the döbel is. With floor
pavements use longer döbel's.




Detail "Z"
Grundplatte
base plate



We point out the minimum requirements of the function on our plans. The condition of the local realities (e.g. ground under the foundation does not lie in our responsibility if necessary an Architect must do individual specified work.

Zeichnungsnr. 260HL10051		Nasse ohne Toleranzangaben		Massstab: Werkstoff / Heizzeug - / -		Gewicht:	
		Bearb.	Datum	Nr.	Bemerkung	2	60
		22.03.10	M.G.		mit Standard roarmen With standard arms		SST
					Zeichnungsnr. 6917-6-EINBAU		
		Zeichnung				Fertigt für: Frezat durch:	
Nr.	Aenderungen	Inhalt		Name		Von	
-	-	-		-		Blatt	

All Mass in Millimeter
all measure in millimeter
subject to alterations!
Mass- und Konstruktionsänderungen vorbehalten!




4. Safety regulations

If you use the automotive lift, the German following regulations are to be considered:
BGG945: Examine of automotive-lifts; BGR500 Using automotive-lifts; (VBG14).

Especially the following regulations are very important:

- The laden weight of the lifted vehicle must not exceed 6000 kg for the automotive lift.
- The automotive lift must be in its lowest position (fully collapsed), before the vehicle can be driving on to the lift. Only then can the vehicle be lifted.
- While working with the lift the operating instructions must be followed.
- Vehicles with low clearance or vehicles that are specially equipped should be pre tested to ensure that they clear the lift ramp to avoid damage.
- Only trained personnel over the age of 18 years old are to operate this lift.
- No one is to stand within the working area (danger area) during lifting and lowering
- No one is to be raised or lowered either directly or in a vehicle by the automotive lift.
- No one is to climb onto the automotive lift or onto an already raised vehicle.
- The automotive column lift must be checked by an expert after changes in the construction have been made.
- The main switch must be switched off and locked before work on the vehicle can commence. This is a safety precaution to ensure that the lift does not move during work.
- The main switch must be switched off and locked before any maintenance or repair work on the automotive lift itself can be carried out.
- During lifting or lowering the operator must observe the vehicle to ensure that the vehicle and the lift are functioning correctly.
- Installation of the standard-mobile column lift in hazardous or dangerous locations such as washing bays is dangerous and is not allowed.
- Check the centre of gravity of the vehicle if heavy parts (e.g. the motor) are removed.
- If heavy parts must be removed (motor) the centre of gravity will change. Secure the vehicle before removing parts to avoid the possibility of the vehicle becoming insecure.
- The capacity is reduced to max. 4200 kg when using the forklift adapters.




5. Operating Instructions



The Safety Regulations must be observed and adhered to while working with the automotive lift. Read the safety regulations in chapter 4 carefully before working with the lift!

5.1 Lifting the vehicle

- Drive the vehicle onto the middle of the lift.
- Secure the vehicle from rolling, put into gear, apply the hand brake.
- Before positioning the arms under the vehicle, press the button; "unlocking the arms" and the pneumatic safety device will open.
Slew the carrying arms under the vehicle and position the pads at the points specified by the vehicle-manufacturer. The arms will lock, if the button "lifting" is pressed.
- Determine the centre of gravity. This point must be located in the middle of the lift. If necessary, adjust the lifting-pads until the vehicle is in the raising condition, that is horizontally level.



Pic 1:

- Check all the danger points of the lift and ensure that there are no objects or people in the working area around the lift or on the lift.
- Switch on the main switch.
- Raise the vehicle. Press the button "lifting" until the wheels are free. If the wheels are free, stop the lifting procedure and check the safety position of the vehicle on the pads again. Check also the locking system of the arms. They must be locked, if the wheels are free. Otherwise lower the lift and position the vehicle one more time.



Closely observe how the vehicle is positioned on the lifting pads. If the vehicle is not correctly positioned on the pads the vehicle is not secure and the risk exists that the vehicle may fall.

- Raise the vehicle to the required working height. Press the button "lifting".
- Observe the complete process.



Pic 2: Main operating unit

A Button "Lifting"

B Button "Lowering"

C Optional: Button "Equalization of the lifting arms"

D Display

5.2 Lowering the vehicle

- Check all danger points of the lift and be sure that there are no objects or people in the working area (danger area) around the lift or on the lift.
- Lower the lift to the required working height or to its lowest (or fully collapsed) position. Press the button "lowering". The lift will rise approx. 1 mm (safety function) before it starts to lower.
- Before the lift reaches its lowest position, the lift stops automatically (CE-Stop). After the lift has stopped, check the danger areas around the lift. Press the button "lowering" again. A warning signal will sound as the lift is further lowered. This is to warn against the risk of crushing as the lift is lowered to its lowest (fully collapsed) position.
- Observe the complete lowering process.
- Once the arms are in the lowest position, press the button "unlocking the arms" and remove the arms from under the vehicle.
- Drive the vehicle off the lift.

5.3 Position measurement

An hall sensor on the hydraulic cylinder monitors the threaded spindle by counting the magnetised increments on the outer ring.

The number of increments counted is transmitted to the Controller. The controller processes this information and regulates both lifting carriages so that they remain level. The current position is shown on the Display.

- The SST (Safety-Star Technology) observes the complete Process of the Lift during "Lifting" and "Lowering".
- The automotive lift lowers with a average load at a rate of 0.05 Meters per sec. If the lift descends noticeable faster there may be a problem with the hydraulic system. The computer-control-system recognizes the problem and switches off the hydraulic supply for the cylinder. The Safety-star system locks and the lift stops.

5.4 Manual equalization of the automotive lift



Only trained and authorized staff are allowed to work with the DIP-switches! The main-switch must be switched off!

- If the Computer Control System recognize a difference of approx. 40 mm between both lifting carriages, it will stop the lift automatically.
- Equalize the lifting carriages.
- Open the electrical box.
- Adjust the following Dip-switch as described: (see Pic. Pos. K)
Dip switch 5 (regulation ON/OFF).
Dip-switch 1 (only lifting carriage 1 moveable).
Dip-switch 2 (only lifting carriage 2 moveable).
Dip-switch 7 (reset – zero the lift in the lowest position).

Enforce the equalisation:

- Equalize lifting carriage 1.
- Move the Dip Switch 5 to the "off" position (regulation off).
- Move the Dip switch 1 to the "on" Position (Dip switch 1 for platform 1).
- Press the button "lifting" or "lowering" and the override switch simultaneously until the platform is level.
- Move the Dip switch 1 to the "off" Position.

- Move the Dip switch Dip 5 to the “on” Position (regulation on).
- Press the button “lowering” until the lift reaches the lowest position so that a reset can then be carried out (see chapter “Reset after an emergency lowering”)
- Remount the covers.



Pic 4:

6. Troubleshooting

If the lift does not work properly, the reason might be quite simple. Please check the lift for the potential reasons mentioned on the following pages. If the cause of trouble still cannot be found, please call technical service.

Problem: Motor does not start!

Potential causes:

No power supply

Main switch is not engaged

The main switch is defective

Fuse defective

The feed line is cut

Thermal switch in the motor is active

The lifting carriages are not within the control limits (window)

Motor is defective

solution:

Check the power supply

Check the main switch

Check the main switch

Check Fuse

Check the complete cable

Let motor cool down

Read chapter 5.3

Call technical service

Problem: Motor starts, lift does not lift!

Potential causes:

The vehicle is too heavy

Level of the oil is too low

The emergency lowering screws are not closed

Hydraulic valve is defective

Gear pump is defective

solution:

unload the vehicle

check the oil level, fill with hydraulic oil as required

Check the emergency lowering screw

Call technical service

Call technical service

Problem: the lift does not lower!

Potential causes:

An obstacle is restricting the lift from being lowered

Hydraulic valve is defective

Fuse is defective

The SST is locked

Button "lowering" is defective

solution:

(see chapter 6.1)

Call technical service

Check the fuse

Call technical service

Call technical service

Problem: the arms do not move

Potential causes:

The unlocking button is defective

Not enough air pressure

Air hose defective

solution:

check the button

check the air pressure

check the air hose

6.1 Lowering onto an obstacle


If the Safety-Star-System recognizes a difference of 40 mm between both lifting carriages it automatically switches off the lift.

6.1.1 Remove an obstacle



Only trained and authorized staff are allowed to work with the DIP-switches! The main-switch must be switched off!

- Remove the cover of the control box.
- Press the button "Reset" (1) and hold it. (see Pic. 5, "Reset Achskontroller 1")



pic 5: Platine - Controller

- Switch off the main switch and wait 5 sec. Hold the reset button.
- Switch on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Move all the Dip-switches to the “off” position.
- Move the Dip-switch 1 and 2 to the “on” position.
- **Caution:** This procedure can only be done when the lift is **not** at its maximum height.
- Closely observe the vehicle on the lift and its reaction.
- Press the “lifting” button until the obstacle can be removed.
- The side of the lift that is higher must be lowered with the help of the corresponding Dip-switch. (see chapter “Equalisation of the two lifting platforms”).
- After equalizing the runways, a reset must be carried out (see the following points).
- Move all the Dip-switches to the “off” position.
- Move the Dip-switch 5 to the “on” position.
- Press the button “reset” (1) and hold it. (Pic. 2)
- Switch-off the main switch and wait 5 sec. Hold the reset button.
- Switch-on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Press the button “lowering” until the lift (both platforms) is in its lowest position (fully collapsed) and the warning signal stops beeping.
- Move the Dip-switch 7 to the “on” position .
- Keep Dip-switch 5 in the “on” position.
- Press the button “reset” (1) and hold it.
- Switch-off the main switch and wait 5 sec. Hold the reset button.
- Switch-on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Keep Dip-switch 5 in “on” position.
- Move Dip-switch 7 to the “off” position.
- Three diodes should now be see on the computer display board. One additional diode should be blinking at the frequency of approx. 1 sec.
- Raise and lower the automotive lift a few times without a load. Observe the process.
- Remount the covers.

6.2 Emergency lowering



A emergency lowering is an intervention into the controls of the lift and can be done only by experienced expert.

The emergency lowering must be carried in this order. Otherwise a malfunction may lead to damage to equipment, injury or even death.



Every kind of external leakage must be removed. This is particularly necessary before an emergency lowering.

The emergency lowering may only be done by persons who are trained in using the lift.

Reasons, that may warrant an emergency lowering are; a defect in the electric system or disturbances of the valves, etc.

In case of power-failure or defective valves it is the possible through the use of suitable tools to lower the lift to its lowest position so that the vehicle can be driven off.

6.2.1 Emergency lowering procedure

- Switch off the main switch and secure it. (lock it)
- Remove the covers of hydraulic unit.
- Secure the danger area around the lift.



Pic 6:

Loosen and remove the 2 lock nuts with a suitable tool (spanner, wrench) in an anti-clockwise direction. Carry out this process on both columns. (Key 41)



Pic 7:

The piston rod at the top of the column may be restricted by dirt and grit deposits. Use a solvent and a lubricant (for an example WD40) to loosen and lubricate the connection. Spray the WD40 generously between the piston rod thread and the bore hole (see arrow). The time taken to remove the dirty deposit will depend on the degree of contamination.



Pic 8:

Loosen the both red locknuts at the hydraulic block. Then loosen the both emergency lowering screws with a suitable tool (size5) maximum 1 turn anticlockwise

Red lock nuts with
emergency lowering screw



Pic 9:

Use the extended threaded socket connection and turn clockwise with an appropriate tool (socket wrench size 24, available at your dealer.). Lower the lifting carriage only 5cm – 10 cm. Repeat this process on the next column and continue until the entire lift is in its lowest position. Only lower each side 5 cm-10 cm at a time.

Repair the defective lift. After this is complete, a "Reset" must be carried out (described in the operating instructions).



Attention!! Lower the automotive-lift only approx. 5cm – 10 cm at a time.



Observe the complete emergency lowering process.



Do not work with the lift until the defective parts are changed.



Recommencement of work can only begin once the lift is deemed to be in perfect condition regarding safety.

- If the lift has been deemed safe to operate, carry out a reset as described in the operating instructions.

6.3 Reset after an emergency lowering



A reset can only be carried out, if the automotive-lift is in its lowest position (fully collapsed).



Access to the DIP-Switch is only possible once the main switch is in the "off" position. Only instructed, authorized technical personnel can carry out the reset.

- a) Drive the vehicle off the lift.
- b) Open the cover of the operating unit.
- c) Open the electrical box door.
- d) Press the button "Reset" 1 (see pic.5) and hold it.
- e) Switch-off the main switch and wait 5 sec while holding the reset button.
- f) Switch-on the main switch and wait 5 sec while holding the reset button.
- g) Let go of the reset button
- h) Press the button "lowering" until both lifting carriages are in their lowest position.
- i) If necessary repeat steps d) to h) several times to be sure that the lift is in its lowest position.
- j) Next, move the Dip-switch 7 to the "on" position.
- k) Keep Dip-switch 5 in the "on" position.
- l) Repeat the steps d) to h)
- m) Next, move Dip-switch 7 to the "off" position. Keep Dip-switch 5 in the "on" position.
- n) Three diodes should now light up on the computer-board. One additional diode should be blinking in the frequency of approx. 1 sec.

- o) Raise and lower the automotive lift a few times without load. Observe the process.
- p) Mount the covers.

7. Inspection and Maintenance



Before conducting maintenance work, preparations must be made to ensure that during maintenance and repair work there is no risk to the safety of people working on or around the lift and also that there is no risk of damage to equipment being used on or around the lift.

To guarantee the utmost availability and to ensure that the lift remains functional, maintenance work contracts are organised between our clients and their local retailers.

A service must be performed at regular intervals of 3 months through the operator in accordance with following service manual. If the lift is in continuous operation or in a dirty environment, the maintenance rate must be increased.

During daily operation the lift must be closely observed to ensure that it is functioning correctly. In the case of malfunction or leakage the technical service must be informed.

7.1 Maintenance plan of the lift



Before beginning any maintenance work isolate the power supply. Secure the main switch (lock it). Secure the danger area around the automotive lift and secure the lift against unintentional lowering.

Maintenance plan	Period
Check the condition of the type plate, the short operating instruction and the sticker "capacity".	min. 1x yearly
In case of heavy dirt deposit clean the piston rods of the hydraulic cylinders from deposit. Remove the cover of the lift. If necessary raise the lift to the highest position. Grease the piston rods with a high capacity lipid (approx. 5 g of S2 DIN51503 KE2G of the Renolit Company).	min. 1x yearly
Clean and check the moving parts. Lubricate the moving parts of the lift (hinge bolts, rolls, sliding surfaces). Grease with a multipurpose lipid (example: Auto Top 2000 LTD. Agip).	min. 1x yearly
Check the sliding block of the lifting carriage. In case of wear or damages exchange it. Grease it with a multipurpose fat.	min. 1x yearly
Grease the lubricating nipples of the double joint arms with a multipurpose fat.	min. 1x yearly
Check the hydraulic tubes/hoses for leakage. Check the screw fittings.	min. 1x yearly
Check the oil level. Fill in a clean, high quality oil (32 cst) in the tank.	min. 1x yearly
The hydraulic oil has to be changed at least once a year. To change the oil, lower the lift into the lowest position. Empty the tank and replaced clean oil, approx. 21 litres are needed. A high quality hydraulic oil is recommended, its should be 32 cst. (e.g. HLP 32 LTD. OEST Company)	min. 1x yearly

Use a ATF-Suffix hydraulic-oil (OEST Company) if the ambient temperature is under 5 degree centigrade. After the fill up, the hydraulic oil must be between the upper and low marking of the oil level gauge.	
Check all welded joints for cracks on the automotive-lift. If any cracks are found on the lift cease use immediately. Switch-off and secure the main switch (lock) and call the service partner.	min. 1x yearly
Damage to external surfaces, must be immediately repaired. If these repairs are not made immediately, permanent damage to the powder-coated surface may result. Repair and clean damaged areas with an abrasive paper (grain 120). After this is complete, use a suitable paint (observe the RAL Number).	min. 1x yearly
Check the zinc surface and repair it with a suitable tool. Use abrasive paper (grain 280). White rust can result from moisture laying in certain areas for long periods of time. Poor aerating can also result in rust formation. Rust may result from mechanical damage, wear, aggressive sediments (de-icing salt, liquids) or insufficient cleaning. Repair and clean these areas with abrasive paper (grain 280). After this is complete, use a suitable paint (observe the RAL Number).	min. 1x yearly
Check the condition and function of the safety device CE-Stop and the acoustic signal, foot protection, locking system of the lifting arms, rubber pads	daily
Check the Battery of the controller (ASC). The Battery has a working life at normal business between 4 ½ - 5 Years (manufacturers statement). To avoid a permanent data-loss through an empty battery, you must examine the battery of the controller during the regularly maintenance. The measuring can only take place at the controller which was switched-off. The measuring is possible with a commercial tensiometer. Standard voltage approx. 3.2 V (no exchange necessary), but a value under 2.9 V, the controller must be exchanged. Send the controller to the Nußbaum Headquarter. Previously, contact your service partner.	min. 1x yearly
Check the electrical cable, plugs for damages	min. 1x yearly
Check the condition and function of the electrical box, press button, signal lamps and labelling.	min. 1x yearly
Check the condition of the cable channels.	min. 1x yearly
Check the condition of the concrete floor at the dowels.	min. 1x yearly
Check the turning moment of the screws (see the list)	min. 1x yearly

Turning moment for screws

property class 8.8

0,10* 0,15** 0,20***

M8	20	25	30
M10	40	50	60
M12	69	87	105
M16	170	220	260
M20	340	430	520
M24	590	740	890

Drehmomenttabelle 8.8-10.9 E

property class 10.9

0,10* 0,15** 0,20***

M8	30	37	44
M10	59	73	87
M12	100	125	151
M16	250	315	380
M20	490	615	740
M24	840	1050	1250

- * sliding friction 0,10 for very good surfaces, lubricated
- ** sliding friction 0,15 for good surfaces, lubricated oder dry
- *** sliding friction 0,20 surface black or phosphatized, dry

Pic 10:

7.2 How often must the lift be cleaned?

A regular and appropriate maintenance practice will aid the preservation of the lift.

No guarantees can be given when damage (egg rust or fading colour) is the direct result of poor maintenance and cleaning practice.

Regular cleaning of all kinds of dirt is the best protection against wear and the formation of rust and will prolong the life of the lift

- Dirty deposits that can cause rust include:

- de-icing salt
- sand, pebble stone, natural soil
- all types of industrial dust
- water; also in connection with other environmental influences
- all types of aggressive deposits
- constant humidity caused by insufficient ventilation

Obviously this is dependent on the type of work being done with the lift, the degree of cleanliness of the workshop and location of the lift. The degree and amount of dirt is dependent on the season, on the weather conditions and the ventilation of the workshop.

During poor conditions it may be necessary to clean the lift once week, but cleaning once a month will suffice.

Clean the lift and the floor with a non-aggressive and non-abrasive detergent. Use a gentle detergent to clean the parts. Use a standard washing-up liquid and lukewarm water.

- Do not use steam jet cleaners.
- Remove all dirt carefully with a sponge or if necessary with a brush.
- Ensure that no washing-up liquid is left on the lift after cleaning.
- Do not use aggressive means for cleaning the workshop floor and the automotive lift.
- A permanent contact with any kind of liquid is not allowed. Do not use high pressure devices for cleaning the lift.

8. Security check

The security check is necessary to guarantee the safety of the lift during use. It has to be performed in the following cases:

1. Before the initial operation, after the first installation.
Use the form “First security check before initiation”
2. In regular intervals after the initial operation, at least annually.
Use the form “Regular security check at least annually”
3. Every time the construction of that particular lift has been changed.
Use the form “Extraordinary security check”




The first and the regular security check must be performed by a competent person. It is also recommended to carry out a service on the lift at this time.



After the construction of the lift has been changed (changing the lifting height or capacity for example) and after serious maintenance works (welding load bearing parts) an extraordinary security check must be performed by an expert.

This manual contains forms with a schedule for the security checks. Please use the appropriate forms for the security checks. The forms should remain in this manual after they have been filled out. A short description about special safety devices follows.

9. Handing over and Initiation



9.1 Regulations

- The installation of the lift is performed by trained technicians of the manufacturer or one of its distribution partners. If the operator can provide trained mechanics, he or she can install the lift by him or herself. The installation has to be done according to this regulation.
- Installing the standard-automotive lift in a hazardous location or a washing bay is not allowed..
- Before installation a sufficient foundation must be constructed. If the foundation is already constructed then proof that the foundation conforms to the standard is required.
A level foundation for the installation is required. The foundations must be based in a frost resistance depth, both outdoors and indoors in a position where the installer believes there is no chance of frost.
- An electrical supply 3~/N+PE, 400 V, 50 Hz must be provided.
The supply line must be protected with a time-lag fuse T16A (VDE0100 German regulation).
The minimum diameter amounts to 2.5 mm².
- All cable ducts must be equipped with protective coverings to prevent accidents.

9.2 Erection and bolting down the lift

Before the installation of the lift, secure the installation area to prevent access to unauthorised persons. Use devices such as cranes, fork lift trucks and supports to transport the lift and avoid accidents.

- Carefully remove the lift from its wooden crate. Check the lift for damage.
- Position the columns as described in the foundation diagram drawing.
- Connect the power supply to the column (by customer).
- Connect the cables between the columns.
- Check the positions of the columns again.
- Fill tanks, approximately 17 litres of hydraulic oil per tank.
- Bore holes in the foundations so that base plates and be bolted down. Clean the holes with compressed air. Put masonry bolts in and secure. The lift-manufacturer demands Liebig safety masonry bolts or equally good bolts from another manufacturer (with licence). Be sure to observe their regulations (bore hole, torque...). Before bolting, check that the concrete-floor is of quality C20/25. If the entire floor is concrete (there is no surface covering), bolts must be selected according to a floor without a surface covering. If the ground is covered with floor tiles or some other form of surface covering, the bolts must be selected according to the floor with floor-covering.
- Press the button "lifting" observe the rotation of the motor.
- If the automotive-lift does not rise, check the rotation-direction of the motor. Otherwise, change two phase of the power supply. (only with 3 phases)
- Fine adjustment of the lift: If necessary use metal sheets to level out an uneven floor. A continuous contact between the floor and the base plate must be ensured to avoid hollow spaces.
- Tighten the masonry bolts to there specified moments using a torque wrench.



Each masonry bolt must be tightened to the specified torque. Otherwise the normal function of the lift can not be guaranteed.

Observe the regulations of other masonry-bolt manufacturers.

- If necessary, carry out a reset before the first operation. (see chapter 6.3)
- Raise the lift to a height of about 800 mm.
- Mount the lifting arms.
- Raise and lower the lift several times without a load (vehicle) to the upper and lower limits.
- Check that the safety devices are functioning correctly.
- Raise and lower the lift several times with a vehicle to the upper and lower limits. (see chapter 5.2)
- Check the hydraulic system for leakages.
- Check that the masonry-bolts are correctly torque again.



In the case of any faults, call the customer service immediately!

9.3 Initiation



Before the initiation a security check must be carried out. Therefore use the form: First security check.

If the lift is installed by a competent person, he or she is to perform the security check. If the operator installs the lift by him or herself, he or she must instruct a competent person to perform the security check.

The competent confirms the faultless function of the lift in the installation record and the form for the security check and authorises the use of the lift.



Please send the completed installation record to the manufacturer after installation.

9.4 Change of lift location

If the place of installation is to be changed, the new place has to be prepared in accordance to the regulations of the first installation. The change should be performed in accordance with the following points:

- Raise the lift to a height of about 1000 mm.
- Remove the cover of the tank.
- Remove the lifting arms.
- Lower the lift to its lowest position.
- Remove the oil from tank.
- Remove all electrical cables between the columns.
- Disconnect the power supply.
- Transport the automotive-lift to the its new location
- Install the lift in accordance with chapter 9 " Installation and Initiation".




Use new masonry-bolts, the used bolts can not be used again.



***A security check must be performed before reinitiation by a competent person.
Use form "Regular security check"***

Masonry-Bolt length without floor pavement or tile surface




Liebig-masonry bolts

Bolt-type	BM16-25/100/40
Drilling depth	a 200
Min. anchorage depth	b 165
Thickness of concrete	c 260
Diameter of bore	d 25
Thickness of the lift-pieces	e 0-35
Number of bolts	14
Starting torque	115 Nm

You can use equivalent dowels from another dowel manufacturer (with license) but observe their regulation.

Masonry-Bolt length with floor pavement or tile surface



Liebig-bolts

bolt-type

BM16-25/100/65 BM16-25/100/100

Drilling depth

a 125 125

Min. anchorage depth

b 100 100

Thickness of concrete

c min.250* min.250*

Diameter of bore

d 25 25

Thickness of the lift-pieces

e+f 40-65 65-100


Number of bolts

20 20

Starting torque


115Nm 115Nm

You can use equivalent dowels from another dowel manufacturer (with license) but observe their regulation.





fischer-Dübel				2.60 HL SST ^e
Dübel typ of dowel type de cheville		FH 15/50 B	FH 18 x 100/100 B	FH 24/100 B
Bohrteufe drilling depth Profondeur de l'alésage	t _d	145	230	255
Mindestverankerungstiefe min. anchorage depth Profondeur minimale d'ancrage	h _{ef}	70	100	125
Betonstärke thickness of concrete Epaisseur du béton	c	siehe den aktuellen Fundamentplan see current foundation-diagram drawing vois le plan de fondation actuel		
Bohrerdurchmesser diameter of bore Diamètre de l'alésage	d ₀	15	18	24
Bauteildicke thickness of the lift-piece Epaisseur de la pièce	t _{fix}	0-50	0-100	0-100
Anzugsdrehmoment Nm turning moment moment d'une force	M _d	40	80	120
Stückzahl piece number nombre des pièces	a b c d e f g	4 8 10 12 14 16 20		

Montage




Es können auch gleichwertige Sicherheitsdübel anderer Hersteller (mit Zulassung) unter Beachtung deren Bestimmungen verwendet werden.
It is possible to use equivalent safety-dowels (with license) of other manufacturer but observe their regulations.
Des chevilles des autres marques (autorisées) peuvent aussi être choisies en respectant les directives du fabricant.




Änderungen vorbehalten!
subject to alterations!
sous réserve des modifications!

Hilti-Dübel					2.60 HL SST ^e	2.60 HL SST ^e
Bodenbelag (Estrich, Fliesen)		ohne Bodenbelag	ohne Bodenbelag	mit Bodenbelag	ohne Bodenbelag	mit Bodenbelag
Dübel type of dowel type de cheville		HSL-3-G M10/40 Art.Nr.371797	HSL-3-G M12/50 Art.Nr.371800	HSL-3-G M12/100 Art.Nr.371831	HSL-3-G M16/50 Art.Nr.371803	HSL-3-G M16/100 Art.Nr.371832
Bohrteufe drilling depth Profondeur de l'alésage	h1	90	105	105	125	125
Mindestverankerungstiefe min. anchorage depth Profondeur minimale d'ancrage	hef	70	80	80	100	100
Betonstärke thickness of concrete Epaisseur du béton	c	siehe den aktuellen Fundamentplan see current foundation-diagram drawing voir le plan de fondation actuel				
Bohrerdurchmesser diameter of bore Diamètre de l'alésage	do	15	18	18	24	24
Bauteildicke thickness of the lift-piece Epaisseur de la pièce	tfix	0-40	0-50	0-100	0-50	0-100
Anzugsdrehmoment Nm turning moment moment d'une force	T _{inst}	35	60	60	80	80
Gesamtlänge Total length Longueur totale	l	135	164	214	188	238
Gewinde Thread fil	M	10	12	12	16	16
Stückzahl piece number nombre des pièces	a			4		
	b			8		
	c			10		
	d			12		
	e			14		
	f			16		
	g			20		



Es können auch gleichwertige Sicherheitsdübel anderer Hersteller (mit Zulassung) unter Beachtung deren Bestimmungen verwendet werden.
It is possible to use equivalent safety-dowels (with license) of other manufacturer but observe their regulations.
Des chevilles des autres marques (autorisées) peuvent aussi être choisies en respectant les directives du fabricant.



Änderungen vorbehalten!
subject to alterations!
sous réserve des modifications!

Hilti-Injections dowel		HL 2.60 SST ^e					
Betonboden / concrete floor		ohne Bodenbelag / without floor pavement (tiles)					
Dübel type of dowel type de cheville		HIT-V-5.8 M10x130	HIT-V-5.8 M12x150 Art.Nr.387061	HIT-V-5.8 M16x200 Art.Nr.956437			
Bohrteife (mm) drilling depth Profondeur de l'alésage	h_0	90	108	144			
Mindestverankerungstiefe (mm) min. anchorage depth Profondeur minimale dáncreage	h_{ef}	90	108	144			
Betonstärke (mm) thickness of concrete Epaisseur du béton	H_{min}	min.120	min.138	min.180			
Bohrerdurchmesser (mm) diameter of bore Diamètre de l'alésage	d_0	12	14	18			
Bauteildicke (mm) thickness of the lift-piece Epaisseur de la pièce	t_{fix}	max.17	max.19	23			
Anzugsdrehmoment (Nm) turning moment moment d'une force	T_{inst}	20	40	80			
Gesamtlänge (mm) Total length Longueur totale	l	130	150	200			
Gewinde Thread fil	M	10	12	16			
Stückzahl piece number nombre des pièces	a	4					
	b	8					
	c	10					
	d	12					
	e	14					
	f	16					
	g	28					
Die Montageanweisung des Dübelherstellers ist Folge zu leisten. Bei Bodenbelag (Estrich/Fliesen) sind längere Dübel zu verwenden.							
Observe necessarily the installation description of the dowel manufacturer. Use longer dowels with version with floor pavement and tiles							
Es können auch gleichwertige Injektionsdübel anderer Hersteller (mit Zulassung) unter Beachtung deren Bestimmungen verwendet werden. It is possible to use equivalent injections dowels (with license) of other manufacturer but observe their regulations. Des chevilles des autres marques (autorisées) peuvent aussi être choisies en respectant les directives du fabricant.							

First security check before installation



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri- fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri- fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....

(Use another form for verification!)

.....
signature of the operator

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Regular security check and Maintenance



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator

If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Extraordinary security check



Complete and leave in this manual

Serial-number: _____

kind of check	all right	defect missing	veri-fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Construction (deformation, cracking)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition surface piston rod	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition electrical wires	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Level of hydraulic oil	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

(mark here applicable, in case of verification mark in addition to the first mark!)

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....
signature of the expert

.....
signature of the operator


If failures must be repaired:

Failures repaired at:

.....
signature of the operator

(Use another form for verification!)

Hydraulic diagram drawing




H-Plan 2.60 HL SST 01-2010

Hydraulic parts list

No.	Description	Order No.
0.1	Oil tank	260HL01520
0.2	Oil filter	980012
0.3	Gear pump 5,8cm ³	1BK7S9,2Q
0.4	Sub oil motor	992463
0.5	Oil level gauge	980098
0.6	Hydraulic valve	980166
0.7	Hydraulic block	99-572-00-01-5
DB1	Pressure relief valve	155211
DB2	Pressure relief valve	155211
M1-M4	Measuring connection	118495
VW1	Proportional valve	WEP06DA01B0240S
VW2	Proportional valve	WEP06DA01B0240S
VW3	4/2 way valve	WE06DA77A0240F
V1	Holding valve	158503
N1	Emergency lowering screw	120026
N2	Emergency lowering screw	120026
SV1	Double seat valve	158641
SV2	Double seat valve	158641
1.0/2.0	Cylinder + unlocking cylinder	260HL22001

Electrical diagram drawing



SCHALTPLAN

Erdung nach örtlichen Vorschriften
Vor Inbetriebnahme prüfen, ob Motorenstrom mit Motorschutzrelais
übereinstimmt. Alle Klemmstaben auf Ordnungsgemäße Verbindung und alle
Kontaktschrauben auf festen Sitz prüfen.
Vor Inbetriebnahme Verdrahtung und Steuerung auf richtige Funktion
überprüfen. Keine Inbetriebnahme von unbefugter Seite vornehmen lassen.
Änderungen vorbehalten

1.) Schaltpläne und Schaltunterlagen
Die Schaltlinien werden von uns nach besten Gewissen angefertigt. Für beigesetzte Schaltpläne und
Schaltunterlagen wird von uns keine Garantie für die Richtigkeit dieser Unterlagen übernommen. Diese
Treft insbesondere für Schaltlinien von uns nach fremden Plänen aufgerufen werden. Diese
Werden von uns nur nach den vom Auftraggeber überlassenen Unterlagen des Herstellers ausgeführt.
Änderungen vorbehalten

2.) Funktionsprüfung der Schaltanlagen
Schaltpläne sind keine Serienereignisse. Bei der Prüfung des Schalterschrankes im Werk können
Fehler wie Fühler, Thermotaste und Motoren nicht einzusezen werden. Auch bei sorgfältiger
Prüfung lassen sich deshalb Funktions- und Schaltungsfehler nicht immer vermeiden.
oder hat die Anwendung zu keinem gegeben. Sie kann daher nicht als Garantie für die
Richtigkeit der Schaltlinien gelten. Bei Übereinstimmung der Schaltlinien mit den technischen
Nachbesserungen einschließlich der Berechnung von Schaltplänen bei nicht von uns in Betrieb
genommenen Schaltlagen werden deshalb nur gegen Berechnung seines unser Service-Bedingungen
ausgeführt. Kosten für Nachbesserungen durch uns vornehmen zu lassen.

OBJEKT : 2. 60 HL SST
ANLAGE :
KUNDE :
SCHALTPLÄNNR: 2. 60 HL SST 12/09/001

3.) Sicherheitsprüfung und Schutzmäßignahmen

Der Schalterschrank wurde unter Beachtung der anerkannten Regeln der Technik nach
VDE100/0113 sowie der Unfallverhütungsvorschrift VBG/elektrische Anlagen und
Betriebsmittel geprüft. Es darf nicht ohne die zuständige Fachbehörde und geprüft
Stromanspruchprüfung und dieser Toleranzprüfung des Schalterschrankes nach VDE100/5 73
1. Prüfung der Wärmeisolation bei indirektem Berühren
2. Prüfung der Wärmeisolation bei direktem Berühren nach VDE100/5 73
3. Prüfung der Wärmeisolation und Überprüfung nach VDE550/11 87.
1. Schutz gegen direktes Berühren nach VDE100/5 73 Par. 4
2. Schutz bei indirekten Berührern nach VDE100/5 73 Par. 5

Diese Schaltpläne sind unser geistiges Eigentum.
Sie dürfen ohne unsere Genehmigung weder ver-
vielfältigt noch Dritten weitergegeben werden!

Ränderung	Datum	Name	Norm	Bearb	Datum	Bearb	Nr.	Deckblatt
								b1 1 13 b1

Inhaltsverzeichnis

1

Mussbaum	Hussbaum Hebe-technik GmbH & Co KG Kerstenstraße 24 D-27664 Neumünster Tel. +49 040 952 0990 Fax: +49 040 9853 0787	2. 60 HL SST	
änderung	Datum Bearb BUE Gepr 02.08.2010	Urspr. Ers. f.	Inhaltsverzeichnis Er s. d. §1 2


ÄNDERUNGS-INFORMATIONEN


Nr.	Datum	Firma	Bearbeiter	Aenderungen	ORT/SEITE
1	02.08.2010	NB	Boe	Motorleistung von 3kW auf 1.5kW angepasst	4

卷之三

1

10







4


Änderung	Datum	Name	Norm	Urspr.	Ers. f.	Ers. d.	Steuer Spannung	b1	5
								-	13 b1

6

Nussbaum Hebeotechnik GmbH & Co. KG Körber Straße 24 D-7464 Schönaich Tel. (0 71 61) 9 53 0 Fax. (0 71 61) 9 53 0 0 78 7







Bediensäule

Gegenseite

Ausgleich

7

Änderung	Datum	Name	Norm	Ers. f.	Ers. d.	Bearb. BIE	Datum	Nussbaum	2. 60 HL SST		-

Nussbaum Hebelechnik GmbH & Co. KG
Körner Straße 24
D-7460 Schwaig - Rothenburg ob der Tauber
Tel. (09161) 75350 Fax. (09161) 75353/75357

b1
13 b1

卷之三

6

Bau teilbezeichnung		Hänge	Bezeichnung	Typen nummer	Lieferant	Artikelnummer
-R1	1		Motorbreitbeleuchtung	993312	Nussbaum	993312
-R1	1		Klemmreitbeleuchtung	993313	Nussbaum	993313
-R1	1		Klemmreit.	993314	Nussbaum	993314
R1	1		Rechnercontroller ASC 4000 Vollversion	940260	Nussbaum	940260
R1	1		Federleiste Gapol für Achscontroller	FEDERLEISTE_GAPOL	Nussbaum	991416
R1	1		Leiterkartenhalter/ Kartenschäfte	120X1002	Zubehör	992045
R1	1		Befestigungssatz für Leiterkartenhalter	120X10052	Zubehör	992046
R1	1		BlechhalterASC			0350H03012
R1	33		Flachsteckhülse 2...8	45165 123 204	RHP	991352
R1	33		Isolierstifte 2...8	F 2...8	RHP	991353
R2	1		Displaysrahmen klein , komplett	24015RM1133	Nussbaum	24015RM1133
R2	1		Display für ASC 4000	DE1014815V-L/Y/L	Nussbaum	240257
R2	1		Displaylabel Achscontroller	990874	Nussbaum	990874
B1	1		HÄLLENEINRICHTSCHALTER H00-161560BL 5-55H01/5	H00-161560BL 5-55H01/5	Nussbaum	990658
B2	1		HÄLLENEINRICHTSCHALTER H00-161560BL 5-55H01/5	H00-161560BL 5-55H01/5	Nussbaum	990658
F1	1		Sicherungsstifte Trimmer 5x20 mm	N4-8 SF	Enteltec	990661
F1	1		Feinsicherung	FEMTICHERUNG	6F	990475
F2	1		Sicherungsstifte Trimmer 5x20 mm	N4-8 SF	Enteltec	990661
F2	1		Feinsicherung	FEMTICHERUNG	6F	990661
F3	1		Sicherungsstifte Trimmer 5x20 mm	N4-8 SF	Enteltec	990661
F3	1		Feinsicherung	FEMTICHERUNG	6F	990124
G1	1		Schalt-/Relaisgrt. Achscontroller DC 24 V / 2...5A	S61-5F-24	Lusti GmbH	940101
H1	1		Diodend alutisicher Signalgäber	B/P 28	Dilirion Components	991331
-J	1		E-Bus mit Monogruppe gelöst 2...> H0L 55T	B1045-0050BL08	Krauth technology	B1045-0050BL08
-J	1		Hohlaxelschlüsseleinsatz 300x400	B1045-0017	Krauth technology	B1045-0017
-J	2		Perfect Kabelverschraubung H25x1.5	SECHSKRANTHMUTTER H25x1.5	Jacobs GmbH	992350
-J	2		Sechskantschrauber H25x1.5	SECHSKRANTHSCHRAUBUNG H25x1.5	Jacobs GmbH	992297
-J	3		Perfect Kabelverschraubung H20x1.5	SECHSKRANTHMUTTER H20x1.5	Jacobs GmbH	992197
-J	3		Sechskantschrauber H20x1.5	SECHSKRANTHSCHRAUBUNG H20x1.5	Jacobs GmbH	992296
-J	2		Perfect Kabelverschraubung H16x1.5	SECHSKRANTHMUTTER H16x1.5	Jacobs GmbH	9921971
-J	2		Sechskantschrauber H16x1.5	SECHSKRANTHSCHRAUBUNG H16x1.5	Jacobs GmbH	992295
K2	1		INDUSTRIEFLÜSIS 24V 4 Wechsler	2701	BFR	990267
K2	1		Industrierelaissockel für 4 Wechsler	110118	BFR	990381
KH1	1		Leistungsschutz 5...> 24 V DC	11612-01 0 24V DC	Lovato electric	990842
-H1	1		Unterplatte 1.5 km	U07HA51-366 T	Hanniang GmbH	992463
O1	1		Hauptplatte Nor-Rus 3D 168 5 5W	A 105 1 3 0200-E/-/50	Herz & Sohn	991403
S1	1		Druckkästle flach o. Tast Platte (H22)	H22-0-X	Heller	920130
S1	1		Tastplatte Pfahl (H22)	H22-0-5-X7	Heller	920131
S1	1		Kontaktblock 15 (H22)	H22-0-X11	Heller	920132
S1	1		Kontaktplatten 15 (H22)	H22-0-X11	Heller	920133
S2	1		Druckkästle flach o. Tast Platte (H22)	H22-0-X	Heller	920130
S2	1		Tastplatte Pfahl (H22)	H22-0-5-X7	Heller	920131
S2	1		Kontaktblock 15 (H22)	H22-0-X11	Heller	920132
S2	1		Kontaktplatten 15 (H22)	H22-0-X11	Heller	920133
S3	1		Druckkästle flach o. Tast Platte (H22)	H22-0-X	Heller	920130
S3	1		Kontaktblock 15 (H22)	H22-0-X10	Heller	920133
S3	1		Start (I) (H22)	H22-0-5-1	Heller	920142
S4	1		Druckkästle flach o. Tast Platte (H22)	H22-0-X	Heller	920145
S4	1		Tastplatte Pfahl (H22)	H22-0-5-X7	Heller	920130
						920131
Änderung		Datum	02.08.2010	Stückliste		13
Änderung		Name	Gepr. 02.08.2010	Ers. f.		+
Änderung		Norm		Urspr.		-
						b1 12 13 b1

Stückliste