

SM245 TWO POST HOIST

UNIVERSAL 4.5 TONNE ELECTRO-HYDRAULIC TWO POST HOIST

OPERATION AND MAINTENANCE MANUAL



**M
O
L
N
A
R**



PART OF THE
STENHØJ GROUP

**Before
taking into operation
check system compo-
nents, control, emer-
gency stop and safety
equipment for condi-
tion, damage and
correct function!**



MOLNAR
PART OF THE STENHØJ GROUP

3 Graham Street
Export Park
South Australia
5950

Tel.: + 61 (0)8 8346 6893
Fax.: + 61 (0)8 8346 0097

E-mail: sales@molnarhoists.com.au
Internet.: www.molnarhoists.com.au

Table of contents

1	General	4
1.1	Information about the operating manual	4
1.2	Explanation of symbols	4
1.3	Warranty and liability	5
1.4	Spare parts.....	5
1.5	Copyright protection	6
1.6	Waste disposal	6
2	Safety	6
2.1	General	6
2.2	Customer's responsibility	8
2.3	Intended use	8
2.4	Work safety	9
2.5	Personal safety equipment.....	9
2.6	Dangers which may arise from the machine	9
2.7	Operating personnel.....	10
2.8	Behavior in case of danger or accidents	10
2.8.1	Preventive measures	10
2.8.2	If the worst comes to the worst: Do the right things!	10
3.	Technical data	11
3.1	Load distribution.....	11
3.2	Technical specifications.....	12
4.	Structure and function	13
4.1	Description	13
4.2	Safety devices fitted on the hoist	14
4.3	Symbols of short operating instructions	15
5	Transport, packing and storage	16
5.1	Safety notes	16
5.2	Transport inspection.....	16
5.3	Packaging	16
5.4	Storage.....	17
6	Installation and start-up	17
6.1	Installation	17
6.2	Start-up	17
7	Operation	18
7.1	Safety.....	18
7.2	Check points before operation	18
7.2.1	Preparations before operation.....	19
7.3	Operation:	19
7.4	Emergency lowering.....	21
8	Maintenance	22
8.1	Safety.....	22
8.2	Maintenance.....	22
8.3	Lubrication.....	23
8.4	Cleaning:.....	24
9	Inspections	24
10.	Malfunctions	25
10.1	Actions in case of malfunctions	25
10.2	Trouble shooting chart.....	25
11.	Oil specifications	27
12	Appendix: Wiring diagrams	28
13	Appendix: Hydraulic diagrams	28

1 General

1.1 Information about the operating manual

This operating manual describes the installation, operation and maintenance of the machine. Strict compliance with all the specified notes on safety and instructions is essential for safe working and proper handling of the equipment.

Apart from that, all accident prevention instructions valid at the place of use and the general safety regulations must also be adhered to.

This operating manual is part of the product and should always be kept in the immediate vicinity of the machine, accessible for the personnel entrusted with installation, operation, maintenance and cleaning.

For better representation of the explanations, the graphical artwork in this manual is not strictly according to scale, but may slightly vary from the actual design of the machine.

The operating manuals of the supporting components apply alongside this operating manual. Please observe the notes contained therein - especially the safety notes.

1.2 Explanation of symbols

Important safety and machine-technical notes in this operating manual are marked with symbols. The notes must be adhered to in order to avoid accidents, personal injuries and damage to property.



WARNING!

This symbolizes dangers that can lead to adverse effects on health, injuries, permanent physical damage or to death.

Adhere at all costs to the notes specified regarding work safety, and be particularly careful in these cases.



WARNING! Danger of electric current!

This symbol draws attention to dangerous situations involving electrical currents. There is a danger of serious injury or death if the safety notes are not complied with. The work may only be carried out by qualified electricians.



ATTENTION!

This symbolizes notes, which if not complied with, can lead to damages, malfunctions and/or breakdown of the machine.



NOTE!

This symbol highlights tips and information that are to be observed for efficient and disruption-free operation of the machine.

1.3 Warranty and liability

All information and notes in this operation manual are provided under due consideration of valid regulations, the latest technical status of development as well as our years of expertise and experience.

The translation of this operation manual has also been made to the best of our knowledge.

We do not accept any liability for errors in translation. The version marked of the operation manual marked with "Original version" on the front page of the operation manual supplied with the hoist shall be binding.

For optional design versions, the use of additional ordering options or the implementation of the latest technical modifications the actual scope of delivery may differ from the descriptions and illustrations in this manual. If you have any questions please contact the manufacturer.



NOTE!

This operation manual must be thoroughly read before starting any work with the equipment, especially before commissioning ! The manufacturer assumes no liability for damages or disruptions that occur as a result of non-compliance with the operation manual.

This operation manual must be kept at the hoist and accessible for all persons working on or with the hoist. Handing over the manual to third party is not permitted and is subject for compensation. Further rights remain reserved.

We reserve the right to technical changes to the product within the framework of improving the usability and further development.

This hoist is guaranteed, covering faults due to manufacturing or material defects, provided that the installation, operation and maintenance instructions are observed. The warranty implies that during the warranty period the manufacturer is committed either to repair or to replace – after own decision - defective spare parts fitted in the hoist. No other warranty claim can be put in under warranty.

1.4 Spare parts

IMPORTANT: Spare parts used in the lifts are quality tested and comply with the criteria laid down in DS/EN 1493:2010. Please note that the use of safety spare parts or other essential components which do not fulfill these criteria may result in the type approval becoming void and the hoist will thereby no longer keep the safety regulations defined by the manufacturer together with the relevant authorities.

The manufacturer's product/deficiency liability and warranty cannot be claimed if concrete damages or failures are a result of the use of spare parts not originating from the factory.

1.5 Copyright protection

This operating manual is to be treated as confidential. It is solely intended for persons having to work on or with the equipment. Passing this operating manual on to third parties without a written confirmation is not permitted. If this should be required, please contact the manufacturer.



NOTE!

Contents, texts, drawings, pictures and other representations are protected by copyright law and are subject to further commercial protection rights. Any misuse is punishable.

Reproduction of any kind - even in form of excerpts - as well as the utilization and/or disclosure of its content without the written consent of the manufacturer is not permitted.

Violations oblige to compensation. Further rights remain reserved.

1.6 Waste disposal

If no agreement concerning take-back or waste disposal has been made, disassembled components must be passed on for recycling after correct dismantling:

- Metal material residues must be scrapped
- Plastic elements must be forwarded for recycling of plastics
- Other components must be sorted by material properties



ATTENTION!

Electric scrap, electronic components, lubricants and other auxiliary materials must be treated as hazardous waste and must only be disposed of by specially approved waste disposal companies!

Consumables like greases, oils, conserving and cleansing agents must be removed from the device in a type specific and environmental manner. Use suitable and approved storage containers for the respective consumables. Mark these containers according to their content, filling level and data and store them until final waste disposal in such a way, that any accidental use is ruled out.

2 Safety

This section offers an overview of all important safety aspects for an optimal protection of personnel against danger and ensures safe and disruption-free operation of the machine.

In addition to this, concrete notes on safety to avert danger are provided and marked with symbols in the individual chapters. Furthermore, any pictograms, signs and labels on the machine are to be observed and kept legible at all times.

2.1 General

At the time of development and manufacture the equipment complies with the valid and established technical rules and regulations and is safe to operate. However, danger may arise from this machine if it is used unprofessionally by untrained personnel, or if it is used improperly or not for the purpose it is intended for. Each person entrusted with work on or with the machine must have read and understood the operating manual before starting work.

The customer is advised to demand a written confirmation that all relevant persons have read the operating manual.

Changes of any kind as well as attachments or conversions to the machine are prohibited.

Safety, warning and operation related decals on the machine must always be kept in legible condition. Damaged decals or stickers must be immediately replaced.

Specified settings and adjustment ranges must be strictly complied with.

On the following page you can find an example of the EC Certificate of Conformity.
The original certificate is part of the technical documentation supplied with the hoist.



Occupational Health and Safety Act 2004, OHS Regulations 2017
Equipment (Public Safety) Act 2004, Equipment (Public Safety) Regulations 2017



NOTICE OF PLANT DESIGN REGISTRATION

Registration Holder	R & H (Wendeng) Engineering Co Ltd
Plant Type	Vehicle Hoist
Representational Drawing(s)	RH-2PGA-40BMW
Design Description and Extent	Model No. SM245
Technical Information	Type: 2 Post Max. SWL: 4500 kg Max. Working Height: 1.89 m
Manufacturer	R & H (Wendeng) Engineering Co Ltd
Registration Number	V1701292
Date of Registration	28 August 2017
Published technical standards or engineering principles	EN 1493: 2010 Vehicle Lifts

(as listed by designer and confirmed by design verifier)

2.2 Customer's responsibility

This operating manual should always be kept in the immediate vicinity of the machine, accessible for the personnel entrusted with installation, operation, maintenance and cleaning.

The machine must only be operated in technically perfect and safe condition.

Always ensure free access to all safety features and check these at regular intervals.

Details concerning industrial safety refer to directives of the European Union valid at the time the machine was manufactured. The customer is obliged to determine compliance of work safety measures specified with the current status of legal statutes and to observe any new regulations over the entire period in which the machine is used. Outside of the European Union, the laws on industrial safety and regional directives and regulations valid at the place of use of the machine are to be complied with.

The generally valid notes on industrial safety and accident prevention instructions as well as the valid environmental protection regulations applicable at the place of use are to be observed and adhered to alongside the notes on industrial safety in this operating manual.

The customer and personnel authorized by him/her are responsible for the disruption-free operation of the machine as well as for unambiguous determination of responsibilities during installation, operation, maintenance and cleaning of the machine.

Details of the operating manual are complete and must be adhered to without limitation!

Furthermore, the customer must also ensure that:

- Other dangers that result from special working conditions at the place of use are determined in a risk assessment.
- All other instructions and notes on safety that result from the risk assessment of workplaces on the machine are summarized in operating instructions.

2.3 Intended use

Operational safety is only guaranteed when adhering to the intended use of the device.

This lifting device is specially developed to lift motor cars and we strongly recommend not to lift any other equipment with this automotive lift.

The lifting platform has been designed and built for the use inside workshops.

Use of the hoist for undersealing of cars and car wash is not allowed.

Riding, climbing and/or standing on the lifting platform as well as using it for lifting or lowering loads other than the ones specified above or installing and operating it outside in an unprotected environment is prohibited.



ATTENTION!

Any other use of the device that differs from this or exceeds this is prohibited and is not considered unintended use!

Claims of any kind against the manufacturer and/or his authorized representatives resulting from damage caused by unintended use of the device are excluded. The customer is solely liable for any damage occurring during unintended use.

Intended use also includes correct adherence to assembly, operating, maintenance and cleaning instructions.

2.4 Work safety

Compliance with the notes on safety can help to avoid personal injury and material damage when working on the machine. Failure to comply with these notes will cause a considerably risk of injury for persons and danger of damage or destruction of the machine.

Non-compliance with the safety regulations causes the exclusion of any liability or compensation claims against the manufacturer or his representative.

2.5 Personal safety equipment

In principle, the following is to be worn when working on or with the machine:

Protective working clothes

Tight fitting work clothing (minimal tear strength, no wide sleeves, no rings or other jewelers etc.)

Safety gloves



Safety boots

for protection against heavy falling down objects and slipping on non-skid proof ground



2.6 Dangers which may arise from the machine

The machine was subjected to a risk analysis. The resultant construction and design of the machine corresponds to the current status of technology.

However, certain remaining risks cannot be avoided!

This device works with electrical voltage.



WARNING! Danger of electric current!

Electrical power can cause severe injuries. There is a danger to life caused by electric current if the insulation or individual components are damaged.

Switch off the main switch and secure against switching on again before maintenance, cleaning or repair work. Switch off the power supply before starting work in the electrical system and make sure that the system is dead. Do not remove any safety features or do not modify such installations in a way that would adversely affect their function.

The equipment is supported by hydraulic components.



WARNING! Danger of injury!

Hydraulic power can cause severe injuries. In case of damage to individual components fluid may escape under high pressure and cause injury and material damage!

Always relieve all pressures before starting work in the hydraulic system.

Do not remove any safety features or make them inoperative as a result of modifications.

Do not change any pressure settings beyond the values specified in this operating manual.

2.7 Operating personnel

The device must only be operated and serviced by authorized, trained and instructed expert persons who:

- are at least 18 years of age and
- have been thoroughly instructed in operation and
- can provide evidence of their suitability to operate lifting platforms and
- have been entrusted in writing by the operating company to operate the lifting platform

An instructed person is someone who has been trained and, if necessary, instructed practically in the tasks entrusted to him/her and the possible dangers resulting from improper actions; and who has been instructed both about the necessary protective features and about protective measures.

Qualified personnel include those who can assess the work entrusted to them and recognize potential dangers based on their specialist training, knowledge and experience as well as their knowledge of appropriate conditions.

If personnel do not have the necessary knowledge, then they are to be trained accordingly.

The equipment must only be operated and serviced by persons who are able to perform their work in a reliable manner. For this purpose, any mode of operation that adversely affects the safety of persons, the environment or the machine is to be avoided. Persons who are under the influence of drugs, alcohol or medication that affects their responsiveness may under no circumstances carry out work on or with the machine.

The employment of personnel must be based on the applicable regulations concerning age and qualification.

The responsibilities concerning operation and maintenance must be clearly specified in order to avoid uncertainties in competence.

The operator must ensure that unauthorized persons keep a sufficient clearance to the equipment.

The operator is obliged to report immediately any changes to the equipment which adversely affect the safety to the operator.

2.8 Behavior in case of danger or accidents

2.8.1 Preventive measures

- Always be prepared for accidents or fire !
- Keep first aid equipment (first aid kit, blankets, etc.) and firefighting equipment close to hand.
- Make personnel familiar with the location and use of safety, accident reporting, first aid and rescue equipment and have this training confirmed.
- Clear access routes for rescue vehicles.

2.8.2 If the worst comes to the worst: Do the right things!

- Shut down the machine immediately.
- Inform the responsible person at the place of use.
- Alarm a physician and the fire brigade.
- Rescue persons from the danger zone, start first aid measures.
- Keep access routes for rescue vehicles clear.


3. Technical data


3.1 Load distribution

Front load ratio (F_v) : rear load ratio (F_h)

F_v : 60% , F_h : 40%

This assumption is based on a vehicle with a wheel base of 1,00 m.







 = Recommended drive-on direction



3.2 Technical specifications

	SM245
Max. lifting capacity	4.000 kg
Lifting time	30 sec.
Lowering time	30 sec.
Lifting height	1890 mm
Operation temperature	±10°...60°
Noise level (measured at control unit at 1.6 m height)	85dB (A)
Mains voltage	230-400/3/50+N +PE
Power	2,2kW
Revolutions/min	1400 rpm
	400/3/60+N +PE
	2,2kW
	1630 rpm
Pre-fuse	16A slow
Max. operating pressure	160 bar
Setting of pressure control valve max.	165 bar
Output (at 50 Hz)	10 l/min
Oil contents	Approx. 8,4 l

4.3 Symbols of short operating instructions

	<p>The lifting platform must only be operated by authorized persons. Strict compliance with the comprehensive operating manual is mandatory, especially in case of faults</p>
	<p>Climbing up or standing on lifted load or load bearing device is strictly prohibited.</p>
	<p>After slight initial lifting the operator must check that the load is correctly positioned on the load bearing device. Only then the load may be lifted further.</p>
	<p>Always keep an eye on load bearing device and load when moving the lifting platform.</p>
	<p>No persons must be in the movement range of load bearing device or load while the lifting platform is in motion.</p>
	<p>The movement range of load and load bearing device must be kept clear of any obstructions.</p>

5 Transport, packing and storage

5.1 Safety notes



WARNING! Danger of injury!

There is a danger of injury from falling parts when lifting, swinging and lowering. The machine can be damaged or destroyed by improper transporting.

For this reason, fundamentally observe the following safety notes:

- Only use permissible lifting tackle and sling gear with sufficient bearing capacity.
- Only secure the machine on the fastening points provided; do not fasten onto projecting machine parts or eyelets of attached components. Make sure the sling gear is secure !
- Ropes and chords must be equipped with safety hooks. Do not use any torn or worn ropes. Do not lay ropes and chords on sharp edges and corners, do not knot and do not twist. Pay attention to the centre of gravity of the machine when fastening tackle.
- Never lift, swing or lower loads over people.
- Always move the machine with the greatest of care and attention.



WARNING! Danger of life!

Suspended loads can fall down and lead to severe injuries. Do not stand or pass under suspended loads when transporting with lifting tackle!

5.2 Transport inspection

Check delivery immediately on receipt for completeness and transport damage.

Do not accept delivery or only accept under proviso if there is externally recognizable transport damage. Note the scope of damage on the transport documents/delivery note of the carrier. Start complaints procedure.

Complain about hidden deficiencies as soon as they are discovered as compensation claims can only be asserted within the applicable complaints period.

5.3 Packaging

If there is no returns agreement for the packaging, separate materials according to type and size and direct to further use or re-cycling.



ATTENTION!

Always dispose of packaging materials in an environmentally friendly manner and in accordance with the applicable, local disposal guidelines. If necessary, commission a re-cycling company.



NOTE! Good for environmental protection!

Packaging materials are valuable raw materials and can continue to be used in many cases or sensibly reconditioned and re-cycled.

5.4 Storage

Keep packed goods packed up until installation and store such items as specified on the externally attached installation and storage information.

Store packing units only under the following conditions:

- Do not keep in the open-air.
- Store in a dry and dust-free environment.
- Do not subject to aggressive media.
- Protect against direct sunlight.
- Avoid mechanical vibrations.
- Storage temperature: 15 to 25 °C
- Relative humidity: max. 60 %
- For longer periods of storage (> 3 months), check the general condition of all parts and the packaging at regular intervals. If necessary touch up or renew the conservation.

6 Installation and start-up

6.1 Installation

In order to come up to your expectations now and in the future the hoist must be installed in strict accordance with the installation instructions and maintained according to our recommendations.

As agreed, the equipment will be installed by employees of the manufacturer or by authorized partner companies.

Unauthorized assembly or installation work is not permitted.



WARNING! Danger of injury!

Improper installation and assembly can lead to severe personal injury and/or material damage. Installation and assembly work may only be carried out by trained technical staff while observing the safety instructions.

Contact your distributor for the name and address of the nearest authorized service shop.

6.2 Start-up

As agreed, initial start-up of the equipment will be carried out by employees of the manufacturer or by authorized partner companies.

Unauthorized initial start-up is not permitted.

The machine is handed over to the customer following set-up, initial start-up and implementation of test runs by the manufacturer. After this the machine can be operated in strict compliance with the information in the operating instructions.



WARNING! Danger of injury!

Start-up may only be carried out by qualified technical personnel while observing the safety instructions.

7.2.1 Preparations before operation

Check the following items before loading a car on to the hoist;

1. Ensure that hoist is in bottom position.
2. Prohibit access of unauthorized persons to hoist area.
3. If hoist has been out of use for a long time check oil level in pump unit and top up if necessary. Operate hoist up and down 2-3 times without load.
4. When driving a car on to hoist ensure that car is equally distant from each post.
5. Do not change pre-set safety valve pressure as this is adjusted by manufacturer.
6. If oil level is too low hoist cannot operate effectively. Do not operate hoist under these conditions.
7. Before lowering car hoist, check that hoist area is clear and that there are no persons or obstructions to prevent lowering.
8. Passenger transport on hoist or in/on vehicle is forbidden.
9. During winter season, operate hoist 3 to 5 times without load in $5^{\circ}\sim-20^{\circ}$. Do not use hoist in temperature below -20° .

7.3 Operation:

Positioning of vehicle:


Drive the vehicle in between the 2 posts and turn the 4 telescopic arms under the vehicle.

Lifting:

Position the adjustable arms in order that the skid-proof pick-up pads are placed under the supporting parts of the vehicle.

Place the pick-up pads carefully in order to prevent the car from slipping off. The lifting pad must be loaded centrally ! The load distribution permitted between front and rear arms of 2:3 respectively 3:2 must not be exceeded.

Center of lifting point



Adjust the pick-up pads in height so as to catch the 4 lifting points simultaneously.

Push UP -button ↑. Lift the vehicle approximately 10 cm.

Check once more that the pick-up pads are correctly placed and make sure that the arm locks are engaged by pulling the arms backwards and forwards.

Lift the vehicle to required working position. Watch vehicle and lift during the entire lifting movement.

Lowering:

Check that the working area of the hoist is vacant.

Check that all objects have been removed from the working area of the hoist.

Activate Down-button ↓ until the required position has been reached. Watch vehicle and lift carefully during the whole lowering movement.

EC-Stop: When lowering the hoist stops approx. 300 mm from bottom position and an acoustic warning signal is heard. Before continuing the lowering the operator has to check once again that no person can be injured.

Then the hoist can be lowered to bottom position by releasing and re-activating the Down-button, the acoustic warning will be heard until bottom position has been reached.

8 Maintenance

8.1 Safety



WARNING! Danger of injury!

Improperly performed maintenance work can lead to severe physical injury or damage to property. Any work related with care and maintenance must only be carried out by qualified and authorized expert personnel.

Strictly observe when performing maintenance work:

- Switch off the system and secure against switching on again.
- Perform work only with the device stopped.
- Secure movable parts against unintended movement.
- See paragraph "Personal safety equipment"



WARNING! Poisoning hazard!

Lubricants are harmful to health! Skin damage (rashes, inflammation, allergies, etc.) can occur on contact of skin with oils and lubricating greases.

Therefore:

- Please observe instructions and safety data sheets from the manufacturer !
- Lubricants are not to be consumed or swallowed. In case of unintended consumption seek medical advice immediately (bring along the packing).
- When handling lubricants, use suitable skin protective and skin-care products or oil-resistance gloves.
- Rinse any spatters in the eye immediately with a lot of water!
- If the skin is dirtied by any lubricants, wash off immediately with soap and water.



WARNING! Danger of injury!

Lubricants which fall on the ground are a source of danger as they present a risk of slipping. Lubricants are to be adsorbed and removed by spreading sawdust or oil adsorption and afterwards scraped according to local environment regulation.

8.2 Maintenance

Oil level check: Check regularly the oil level in tank under pump. Fill up if necessary.

Oil change: First oil change after 6 weeks' operation, thereafter once a year or once per 1500 lift cycles.

Oil contents: See "Technical specifications".

Oil type: See "Oil specifications".

Expansion bolts:

These must be re-tightened once a year with the following torque:

Model:	Torque:
Thru-bolt	240 Nm
STA	150 Nm

Adjustment of cables:

Steel cables will stretch depending on the operational load and therefore require adjustment as follows, at least once a year:

- Park hoist in adequate working height.
- Check that both carriages are placed at the same height.
- Tighten the lock nut on the two cables, torque 5 Nm.
- Lower hoist again.

Check list and periodic maintenance:

When:	Where:	What:	How ?	Action
Every week	Rubber pads	Wear and deformation	Visually	Replace
	Safety ratchets	Damages	Measure	Replace
Every 3 months	Cables	Wear, breakage og deformation	Visually	Replace
	Pins for arm locks	Funktion of arm locks	Visually	Replace
	Arm locks	Funktion of arm locks	Visually	Replace
	Cover for control unit	Wear and deformation	Visually	Replace
Every 6 months	Sliding blocks	Wear	Visually	Replace
	Electrical components	Damages	Measure	Replace
	Hydraulic oil	Too low oil level	Visually	Replace

8.3 Lubrication

The lift demands inspection every 6 months only, where all movable parts are to be lubricated as follows:

	Where:	What:	Products recommended:
1.	Guiding edges for nylon sliding blocks inside the post	Lithium grease: Lithium soap grease with high pressure additives, consistence NLGI 2 (apply with brush)	- Castrol APS 2* - Shell Retinax EP 2 - Q8 Rembrandt Moly
2.	Cables	Thin oil	
3.	Suspension for arms	Lithium grease	- see item 1
4.	Arm locks	Lubricating oil	

*) Lubricated/greased from manufacturer with these products

8.4 Cleaning:

Cleaning of lifts to prevent corrosion damages.

Corrosive fluids as brake fluid, oil, fuel or other solvents must be wiped off immediately, otherwise damage will occur to the coating.

Special attention must be paid to the corrosive effect of salt in fall and winter periods.

The cleansing agents must not have any abrasive effect, nor contain solvents.

The hoist must be cleaned at least once a week.

The hoist must be cleaned with a non-corrosive cleansing agent.

Clean and wipe the hoist according to the following scheme:

When:	Where:	How:	Remarks:
Every week	Pads	Clean and wipe	
	Arms		
	Carriage		
	Post		

The manufacturer does not accept any claim concerning the paint peeling off or corrosion damages caused by missing or insufficient cleaning or maintenance.

Repair of damages:

Repair of damages on the coating must be carried out immediately in order to minimize the extent of the repair.

The damages will typically be:

Damages which do not affect the metal surface but affects the coating itself

Damages going down into the metal surface.

Repairs:

Contact the manufacturer for guidance.

Please state RAL number of paint.

9 Inspections

Before commissioning the hoist must be inspected according to the local national health and safety regulations.

Operational safety and reliability can only be guaranteed when the condition and function of the hoist are inspected at regular intervals – still according to the local national safety regulations.

10. Malfunctions

10.1 Actions in case of malfunctions

In case of breakdown check the following points:

1. Electricity cut
2. Main fuses
3. Electric motor(s)
4. Cable breakage
5. Obstruction under hoist

If these points are found in order but the hoist is still not working, the safety system has probably been activated, and the hoist must not be started or repaired by unqualified staff. Contact the nearest authorized service shop.

Do not start repairing the hoist until the main switch has been cut off.

Do not disconnect the safety system and do not operate the hoist after breakdown and prior to repair.

10.2 Trouble shooting chart

Symptoms		Check points	Remedy
Cable and safety ratchet	Carriages and arms are not at same level during lifting	1. Check if counter nuts at cable bushing are loose	1. Adjust cable to ensure that carriages are at same level 2. Adjust counter nuts and tighten
	Hoist does not lower when DOWN button is activated	1. Check if ratchet is engaged 2. Check if solenoid coil gets tension	1. Raise hoist a little and lower hoist afterwards 2. Repair cable connection if possible, or lower manually according to emergency lowering procedure
	Carriages and arms are not at same level during lowering	1. Check oil level 2. Check if there is air in the hydraulic system.	1. Fill in oil to correct oil level 2. Bleed hydraulic cylinder
	Safety ratchet does not work, neither during lifting or lowering	1. Check solenoid coil at ratchet	1. Re-fit if necessary and contact autopstenhoj
Cylinder and pump unit	Abnormal noise from motor	1. Max. lifting capacity is exceeded 2. P-max (setting of pressure control valve) is set to low 3. Not sufficient hydraulic oil	1. Limit load to max. capacity or less 2. Adjust to P-max (see technical specifications). 3. Bleed cylinder and fill in oil to correct oil level
	Oil leakage	1. Defective hydraulic hoses 2. Oil leakage from hydraulic unions 3. Defective cylinder seals	1. Replace hydraulic hose 2. Tighten hydraulic unions 3. Call authorized engineer

Symptoms		Check points	Remedy
Cylinder and pump unit	Polluted oil	1. Hydraulic oil polluted by water or other foreign debris	1. Oil change - see oil specifications 2. First oil change 6 weeks after installation 3. Afterwards regular oil changes (see section 8.2)
	hoist does not rise	1. Check for oil leakage or damages on pump unit 2. Check that permissible max. capacity is not exceeded 3. Check that pressure on pressure control valve (P-max.) is correct	1. Call for authorized engineer 2. Limit load to max. capacity or less 3. Adjust valve (see technical specifications)
	hoist does not lower	1. Check if safety ratchet is engaged 2. Check if mains supply is correct	1. Raise hoist a little and afterwards lower 2. Check according to the electrical points
	Lower hoist manually according to emergency lowering procedure and contact afterwards the distributor for assistance		
Electrical components	Motor does not work and/or an abnormal noise from motor is heard	1. Check if motor is damaged 2. Check if fuses are blown 3. Check if push button is defective 4. Check if top limit switch is working 5. Check if motor cable is connected correctly 6. Check that mains voltage is not lower than 200 V	1. Replace motor (call for authorized engineer) 2. Replace fuses 3. Replace push button (call for authorized engineer) 4. Lower hoist and start again 5. Replace supply cable with cable of at least $\varnothing 3,5 \text{ mm}^2$ 6. Increase mains voltage
	Main switch (30 A) is activated	1. Check coil for contactor 2. Check capacity of main switch 3. Check if cable is defective	1. Replace (call for authorized engineer) 2. Replace (call for authorized engineer) 3. Replace after checking
	Motor works but hoist does not rise	1. Check that phases are connected correctly and that motor runs anti-clockwise 2. Check that hydraulic hoses are defective	1. Interchange phases and start again 2. Check according to points for hydraulic cylinder and pump unit

11. Oil specifications

	- Semi-hydraulic hoist (oil in hoist cylinder)	- Full-hydraulic hoist - High-pressure No hoist - 4-post hydraulic hoist - Mistral H - Multiflex	- Scissor hoist (3T) - 2-post hydraulic surface-mounted - Micro 20/26	Lubrication oil for high-pressure hoist
Additives:	Anti-foam, anti-corrosion, anti-oxidation			
Other characteristics:	Water-separating			
Viscosity: (cSt=mm ² /s)	75-120 cSt (40°C)	215 cSt (0°C) 32 cSt (40°C)	140 cSt (0°C) 22 cSt (40°C)	65 - 110 (40°C)
Viscosity index:	Min. 90	150	90	min. 70
Pour point:	Max. -10°C	Max. -10°C	Max. -10°C	Max. -10°C
ARAL	Aral vitam gf 100			Aral konit 30
AVIA	Abilub hydr.oil rsl 100			Avilub mk 2000
BP	Energol hlp 100	Bratran hv 32/shf 32	Bartran hv 22	Vannellus m 2030
CHEVRON	Hydraulic oil 100	Mechanism lps 32		EP industrial oil 68
GALP	Hidrolep 100			NR 30
ESSO STATOIL	Nuto hp 100	Hydraway hv 32	Hydraway hv 22	Protectway 32
FINA	Hydran tsx 100	Hydran ts 32	Hydran ts 22	Arusan 30
GULF - Q8	Q8 haydn 100	Q8 haydn 32	Q8 haydn 22	Q8 wagner 68
MOBIL	Mobil dte 18	Mobil dte 24	Mobil dte 22	Mobilarma 524
NYNÄS	Td 39 ex			Td 31 ex
OK	Ok hydraulic oil 65	Super hydr. oil 32		Ultima eph 68
SHELL	Tellus oil (S) 100	Tellus oil 32	Tellus oil 22	Remula x 20 w
NOROL	Hydraulikolje hm 100			Lagringsolje sae 20
TEXACO	Rando oil 150	Rando oil hd 32	Rando oil hd 22	Regal oil R&O 100
IGOL	Sonhodro 100 / hydro 30			Relax
VALVOLINE	Ultramax hlp 100	Ultramax hvlp 32	Ultramax hvlp 22	Ultramax hlp 68
SUNOCO	Sonvis 8100 wr 100	Sunvis 832 wr-hv	Sunvis 822 we-hv	Sunfill 2630
CASTROL	Hyspin aws/awh 100	Hyspin awh 32	Hyspin aws 22	Rustilo 652

12 Appendix: Wiring diagrams


12.1 Wiring diagram 400 V

13 Appendix: Hydraulic diagrams

13.1 Hydraulic diagram




Wiring diagram
for
SM245





Hydraulic diagram
for
SM245



Date: 03.05.2018

Sign.: LJE

Scale: /

No.



MOLNAR
PART OF THE STENHØJ GROUP

Hydraulic diagram
for
SM245

1. Motor
2. Pressure control valve
3. Non-return valve
4. Solenoid valve
5. Filter
6. Valve
7. Filter
8. Oil tank
9. Cylinder
10. Flow-restricting valve
11. Pump