


# 2.60 HL SST

Automotive-Lift date: 01/2010  
Manual date: 15.03.2012



Original Documentation

## Operating instructions and documentation

**Serial-number:.....**

Retailer address / phone

Made in Germany



# Nussbaum

Otto Nußbaum GmbH & Co.KG//Korker Straße 24D-77694 Kehl-Bodersweier  
Tel: +49(0)7853/8990 Fax: +49(0)7853/8787  
E-mail: [info@nussbaum-lifts.de](mailto:info@nussbaum-lifts.de)// <http://www.nussbaum-lifts.de>

## Contents

Foreword .....	3
Record of installation .....	5
Record of handing over .....	6
1.General Information .....	7
1.1 Installation and service checks of the automotive lift .....	7
1.2 Warning Symbols .....	7
2.Master document of the automotive lift .....	8
2.1 Lift–manufacturer .....	8
2.2 Application .....	8
2.3 Changes to the Lift Construction .....	8
2.4 Displacement of the automotive-lift.....	8
2.5 Declaration of conformity .....	9
3. Technical Information .....	10
3.1 Technical ratings .....	10
3.2 Safety device .....	10
3.3 Data sheet .....	11
4.Safety regulations .....	15
5.Operating Instructions.....	16
5.1 Lifting the vehicle .....	16
5.2 Lowering the vehicle .....	17
5.3 Position measurement .....	17
5.4 Manual equalization of the automotive lift.....	17
6. Troubleshooting .....	18
6.1 Lowering onto an obstacle.....	19
6.1.1 Remove an obstacle .....	19
6.2 Emergency lowering .....	20
6.2.1 Emergency lowering procedure .....	21
6.3 Reset after an emergency lowering .....	22
7.Inspection and Maintenance .....	23
7.1 Maintenance plan of the lift.....	23
7.2 How often must the lift be cleaned?.....	25
8. Security check .....	26
9. Handing over and Initiation .....	26
9.1 Regulations.....	26
9.2 Erection and bolting down the lift.....	27
9.3 Initiation .....	27
9.4 Change of lift location .....	28
First security check before installation .....	33
Regular security check and Maintenance .....	35
Extraordinary security check.....	43
Hydraulic diagram drawing .....	44
Electrical diagram drawing.....	46

## Foreword

Nußbaum lifting systems are the result of a long time experience in the automotive lifting industry. The high quality and the superior concept ensure reliability, a long lift lifetime and above all and economic business solution.

To avoid unnecessary damage, injury or even death, read the operating instructions with care and observe the contents.

Nußbaum lifts is not responsible for incidents involving the use of Nußbaum lifting systems for applications other than those for which they were designed.

***Otto Nußbaum GmbH & Co. KG is not liable for any resulting damages. The user carries the risk alone.***

### Obligations of the user:

- To observe and adhere to the operating instructions.
- To follow the recommended inspection and maintenance procedures and carry out the prescribed tests.
- The operating instructions must be observed by all persons working with or around the lift.
- Above all chapter 4 "Safety Regulations" is very important and must be closely adhered to.
- In addition to the safety regulations stated in the operating instructions manual, the appropriate safety regulations and the operating procedures of the place of operation must also be considered.

### Obligations of the operator:

The operator is obliged to allow only those persons complying to the following requirements to work with or around the unit.

- Persons being familiar with the basic regulations concerning labour safety and accident prevention and being trained to operate the particular unit.
- Persons having read and understood the chapter concerning safety and warning symbols.
- Persons using the lift are required to confirm that they have read and understood the chapter on safety and warning symbols by signing the appropriate form.

## **Dangers when operating the lift:**

Nußbaum-Lifts are designed and built according to technical standards and the approved regulations for technical safety. The use of Nußbaum lifts for purposes other than those for which they were designed, may result in injury or even death.

## **The lift must only be operated :**

- For its appropriate use
- In faultless condition concerning technical security.

## **Organisational Requirements**

- The instructions for use are to be kept at the place of operation being easily access able at any time.
- In addition to the instructions for use, rules pertaining to other regulations i.e. accident prevention and environmental rules are to be observed and adhered to.
- The owner of the Nußbaum lifting system must ensure that operators and persons working with or around the lift occasionally conduct “refresher” courses to ensure that the appropriate operating procedures and safety precautions are known.
- Personal Protective Equipment (PPE) must be used according to the appropriate regulations.
- All safety- and danger signs on and around the lift are to be observed and followed!
- Spare parts must comply with the technical requirements specified by the manufacturer. This is only warranted with original parts.
- Observe and adhere to the specified time intervals between tests and inspections.

## **Maintenance works, repairing faults**

- Adjustments, maintenance, and inspections, are to be followed according to the time intervals specified. Details regarding the exchange of parts and components as mentioned in the operating instructions are to be adhered to.  
These works must only be carried out by expert personal.
- After maintenance- and repair works loose screws, nuts and bolts must always be firmly tightened!

## **Guarantee and liability**

- Our “General conditions of selling and delivering” are in force.  
There will be no guarantee or liability for incidents involving injuries or death or damage to equipment if these incidents are the result of one or more of the following reasons.
- Inappropriate use of the lift
- Inappropriate installation, initiation, operation and maintenance of the lift.
- Use of the lift while one or several security devices do not work, do not work correctly or are not installed correctly.
- Failure to follow the regulations of the operating instructions regarding transport, storage, installation, initiation, operation and maintenance of the lift.
- Unauthorized changes to the structure of the lift without first asking the producer.
- Unauthorized changes of adjustments of important components of the lift (e.g. driving elements, power rating, motor speed, etc)
- Wrong or incorrect maintenance practice.
- Catastrophes, acts of God or external reasons.



**After completely filling out this sheet including signatures, copy and return the original to the manufacturer. The copy must remain in the manual.**

**Otto Nußbaum GmbH & Co. KG  
Korker Straße 24  
D-77694 Kehl-Bodersweier**

### Record of installation

The automotive lift with the

serial number:..... was installed on:.....

at the firm:..... at:.....

The initial safety check was carried out and the lift was started.

The installation was carried out by the operating authority/competent (please delete as applicable).

The initial safety check was carried out by a competent person before the initial operation.

The operating authority confirms the correct installation of the automotive lift, the competent person confirms the correct initial operation.

Used Dowels(\*):.....(Type/Name)

Minimum anchorage depth (\*) kept: ..... mm  ok

Starting torque (\*) kept: ..... NM  ok

.....  
date name of the operating authority signature of the operating authority

.....  
date name of the competent person signature of the competent person

Your customer service:.....(stamp)

(\*) see supplement of the dowel manufacturers

## Record of handing over

The automotive lift with the

serial number:..... was installed on:.....

at the firm:..... at:.....

the safety was checked and the lift was started.

The persons below were introduced after the installation of the automotive lift. The introduction was carried out by either the erector from the lift-manufacturer or from a franchised dealer (competent person).

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name signature

.....  
date name of competent signature of the competent

Your customer service:.....(stamp)

## 1. General Information

The document “**Operating Instructions and Documentation**” contains important information about installation, operation and maintenance of the automotive lift.

- Conformation of **installation of the automotive lift** is recorded on the “Record of Installation” form and must be signed and returned to the manufacturer.
- Conformation of once of, regular and out of the ordinary service checks is recorded in the respective check forms. The forms are used to document the checks. They should not be removed from the manual.

All **Changes to the structure** and any change of **location** of the automotive lift must be registered in the “**Master document**” of the lift

### 1.1 Installation and service checks of the automotive lift

Only specialised staff are allowed to repair and maintain the lift and only these specialised staff are allowed to conduct safety checks on the lift. For the purposes of this document these specialised staff will be called Experts and Competent persons.

**Experts** are persons (for example self-employed engineers, experts) which have received instructions and have the appropriate experience to check and to test the automotive lifts. They are aware of the work involved and know the accident prevention regulations.

**Competent persons** are persons who have acquired adequate knowledge and experience with automotive lifts. They have completed the appropriate training provided by the lift-manufacturer (the servicing technicians of the manufacturer or dealer, are regarded as competent)

### 1.2 Warning Symbols

The three symbols below are used to indicate danger and other important information. Pay attention to areas on and around the lift that are marked with these symbols.



***Danger! This sign indicates danger. Ignoring this warning may result in injury or even death.***



***Caution! This sign cautions against possible damage to the automotive lift or other material objects in the case of improper use.***



***Attention! This sign indicates an important function or other important information regarding the operation of the lift.***

## 2. Master document of the automotive lift

### 2.1 Lift–manufacturer

Otto Nußbaum GmbH & Co. KG  
Korker Straße 24  
D-77694 Kehl-Bodersweier

### 2.2 Application

The automotive lift HL is a lifting mechanism for lifting motor vehicles with a laden weight of up to 6000 kg . The max. load distribution is 3:1 either in or against the drive-on direction.

The capacity is reduced to max. 4200 kg when using the forklift adapters.

The automotive lift has been designed for servicing vehicles only. It has not been designed to carry people. Carrying people either directly on the lift or in vehicles that are on the lift is therefore not allowed.

The installation of the standard lift in hazardous or dangerous locations such as wash bays is dangerous and is therefore not allowed.

### 2.3 Changes to the Lift Construction

**Changes to the construction, expert checking, resumption of work** (date, type of change, signature of the expert)

.....  
.....  
.....

name, address of the expert

.....  
place, date

.....  
signature of the expert

### 2.4 Displacement of the automotive-lift

**Displacement of the automotive-lift, expert checking, resumption of work** (date, kind of change, signature of the competent)

.....  
.....  
.....

name, address of the competent

.....  
place, date

.....  
signature of the competent



## 3. Technical Information

### 3.1 Technical ratings

Capacity	6000 kg
Load distribution	max. 3:1 in or against the drive on direction
Lifting time	approx. 78 sec. with 5900 kg Load
Lowering time	approx. 65 sec. with CE-Stop and 5900 kg Load
Line voltage	3 x 400 Volt , 50Hz
Power rating	1.5 kW (992463)
Motor speed	1400 rotation/min
Pump capacity	5,7 cm <sup>3</sup> (Marz.) 1BK7S9,2Q
Hydraulic pressure	approx. 205 bar
Pressure control valve	approx. 215 bar
Hydraulic pressure (SST System)	approx. 35 bar
Oil tank	per Hydraulic unit approx. 17 Litre
Sound level L <sub>pA</sub>	≤ 70 dB
Connection by customer	3~/N+PE, 400V, 50 Hz fuse 16 Ampere (time-lag fuse) observe your state regulations

### 3.2 Safety device


1. Pressure relief valve  
Protects the hydraulic system from exceedingly high pressures.
2. Holding valve (check valve)  
Safety device against unintentional lowering
3. Lockable main switch  
Safety device against unauthorised operation
4. CE-Stop + acoustic signal (Optional)  
Safety device to avoid crushing (egg. foot in lift recess)
5. Hydraulic unlocking safety system at the cylinder.  
Safety device against unintentional lowering
6. Pneumatic lockable arm  
Protection against unintentional adjusting of the arms
7. Foot-protection at the standard arms  
Safety device to avoid crushing






Bauseitig an der Bediensäule bereitstellen:  
Netzanschluss: 3PH, NPE, 400V, 50Hz  
Absicherung: 16 Ampere t-röge  
für optisches Energieleit:  
Druckluft: lichte Weite 6mm, 6-10 bar

prepared by customer at the operating column:  
power supply: 3PH, NPE, 400V, 50Hz  
fuse: 16 Ampere t-röge  
optical Energy leit:  
Air pressure: 6mm diameter, 6-10bar  
observe the power supply of your country




Anschlussarmierung zum  
vorhandenen Fundament  
vorsehen  
Plan o. armoring with  
the existing foundation

Tragfähigkeit: max. 6000kg  
capacity:





Die Mindestverankerungstiefe des Dübels beachten.  
The minimum anchoring depth of the dowels must be observed.  
Observe the minimum anchoring depth of the dowels, with floor  
pavements use longer dowels.  
Die Montagevorschrift des Dübelherstellers beachten.  
Observe the regulation of the dowel manufacturer.



Zeichnungsnummer 260HL10051	Masse ohne Toleranzgaben		Massstab / Maßstab		Gewicht:
	Bezeichnung	Name	M. G.		
	Datum	22.03.10		Benennung	
	Gen.	M. G.		2.60 HL SST	
	Norm			mit Standardarmen with standard arms	
	Zeichnungsnummer		6917-6-ENBAU		Blatt
				von	
Nr.	Änderung	Datum	Neue Urspr.	Ersatz durch:	

bauseitige  
Versorgungsleitungen  
(Strom, Luft) von oben  
in die Bediensäule einführen  
guide the power supply  
electric air pressure  
from above into the  
column



Wir weisen in unseren Plänen  
auf die Mindestanforderung  
des Fundamentes hin,  
jedoch der Zustand der  
örtlichen Gegebenheiten  
(z. B. Untergrund etc.)  
kann die Ausführung der  
Verankerung beeinflussen.  
Die  
Einbaueinrichtung muss vom  
Planenden Architekten bzw.  
Statiker im speziellen Fall  
individuell spezifiziert werden.


We point out the minimum requirements  
of the foundation in our plans. The  
condition of the local realities  
(e.g.: ground under the foundation etc.)  
does not lie in our responsibility.  
If necessary an Architect must be  
consulted.

Alle Masse in Millimeter  
all measure in millimeter  
subject to alterations!  
Mass- und Konstruktionsänderungen vorbehalten!

Bauseitige Bereitstellung:  
Netzanschluss: 3PH, N+PE, 400V, 50Hz  
Absicherung: 16-Ampere-Tröge  
Druckluft: lichte Weite 6mm, 6-10 bar  
vorbereitet durch den Betreiber

prepared by customer at the operating column:  
power supply: 3PH, N+PE, 400V, 50Hz  
for safety: 16-Ampere-trough  
compressed air: 6-10 bar  
Air pressure: 6mm diameter, 6-10bar  
observe the power supply of your country


Anschlussarmierung zum  
vorhandenen Fundament  
vorsehen  
Plan o. armoring with  
the existing foundation




Betonqualität  
quality of concrete  
min. C20/25  
normal bewehrt  
normal armoring

bauseitige  
Versorgungsleitungen  
(Strom, Luft) von oben  
in die Bediensäule einführen  
guide the power supply  
(electric, air pressure)  
from above into the  
column

Betonstärke ohne Bodenbelag  
(Estrich/Fliesen) min. 250mm  
Thickness of the concrete  
without floor pavement  
(tiles) min. 250mm




Tragfähigkeit: max. 6000kg  
capacity:



Die Mindestverankerungstiefe des Dübels beachten.  
Observe the min. anchorage of the dowels with floor  
pavements use longer dowels.


Die Montagevorschrift des Dübelherstellers beachten.  
Observe the regulation of the dowel manufacturer.



Detail "Z"  
Grundplatte  
base plate

Wir weisen in unseren Plänen  
auf die Mindestanforderung  
des Fundamentes hin.  
jedoch den Zustand der  
Ortlichen abgelesen werden  
(z.B. Untergrund etc.)  
abgelesen werden. Die  
Verantwortung für die  
Ausführung der  
Einbaueinrichtung muss vom  
Planenden Architekten bzw.  
Statiker im speziellen Fall  
individuell spezifiziert werden.

We point out the minimum requirements  
of the foundation in our plans. The  
condition of the local realities  
(e.g.: ground under the foundation etc.)  
does not lie in our responsibility.  
If necessary an Architect must be  
consulted.



Alle Masse in Millimeter  
all measure in millimeter  
subject to alterations!  
Masse- und Konstruktionsänderungen vorbehalten!


Zeichnungsnummer 260HL10051	Masse ohne Toleranzen	Werkstoff / Holzbezug - / -	Benennung HL 6000 SST mit Standardarmen with standard arms	Erstausführung durch: - / -
Bearb. Date	22.03.10	M.G.		
Gepr. Name	Norm			
Nussbaum		Zeichnungsnummer 7229-NB		Blatt von
Nr. Änderung	-	Datum -	Name Urspr.	Ersatz durch: -

## 4. Safety regulations

If you use the automotive lift, the German following regulations are to be considered:  
BGG945: Examine of automotive-lifts; BGR500 Using automotive-lifts; (VBG14).

### **Especially the following regulations are very important:**

- The laden weight of the lifted vehicle must not exceed 6000 kg for the automotive lift.
- The automotive lift must be in its lowest position (fully collapsed), before the vehicle can be driving on to the lift. Only then can the vehicle be lifted.
- While working with the lift the operating instructions must be followed.
- Vehicles with low clearance or vehicles that are specially equipped should be pre tested to ensure that they clear the lift ramp to avoid damage.
- Only trained personnel over the age of 18 years old are to operate this lift.
- No one is to stand within the working area (danger area) during lifting and lowering
- No one is to be raised or lowed either directly or in a vehicle by the automotive lift.
- No one is to climb onto the automotive lift or onto an already raised vehicle.
- The automotive column lift must be checked by an expert after changes in the construction have been made.
- The main switch must be switched off and locked before work on the vehicle can commence. This is a safety precaution to ensure that the lift does not move during work.
- The main switch must be switched off and locked before any maintenance or repair work on the automotive lift itself can be carried out.
- During lifting or lowering the operator must observe the vehicle to ensure that the vehicle and the lift are functioning correctly.
- Installation of the standard-mobile column lift in hazardous or dangerous locations such as washing bays is dangerous and is not allowed.
- Check the centre of gravity of the vehicle if heavy parts (egg the motor) are removed.
- If heavy parts must be removed (motor) the centre of gravity will change. Secure the vehicle before removing parts to avoid the possibility of the vehicle becoming insecure.
- The capacity is reduced to max. 4200 kg when using the forklift adapters.



## 5. Operating Instructions




**The Safety Regulations must be observed and adhered to while working with the automotive lift. Read the safety regulations in chapter 4 carefully before working with the lift!**

### 5.1 Lifting the vehicle

- Drive the vehicle onto the middle of the lift.
- Secure the vehicle from rolling, put into gear, apply the hand brake.
- Before positioning the arms under the vehicle, press the button; “unlocking the arms” and the pneumatic safety device will open.

Slew the carrying arms under the vehicle and position the pads at the points specified by the vehicle-manufacturer. The arms will lock, if the button “lifting” is pressed.

- Determine the centre of gravity. This point must be located in the middle of the lift. If necessary, adjust the lifting-pads until the vehicle is in the raising condition, that is horizontally level.



Pic 1:

- Check all the danger points of the lift and ensure that there are no objects or people in the working area around the lift or on the lift.
- Switch on the main switch.
- Raise the vehicle. Press the button “lifting” until the wheels are free. If the wheels are free, stop the lifting procedure and check the safety position of the vehicle on the pads again. Check also the locking system of the arms. They must be locked, if the wheels are free. Otherwise lower the lift and position the vehicle one more time.



**Closely observe how the vehicle is positioned on the lifting pads. If the vehicle is not correctly positioned on the pads the vehicle is not secure and the risk exists that the vehicle may fall.**

- Raise the vehicle to the required working height. Press the button “lifting”.
- Observe the complete process.



Pic 2: Main operating unit

A Button “Lifting”

B Button “Lowering”

C Optional: Button “Equalization of the lifting arms”

D Display

## 5.2 Lowering the vehicle

- Check all danger points of the lift and be sure that there are no objects or people in the working area (danger area) around the lift or on the lift.
- Lower the lift to the required working height or to its lowest (or fully collapsed) position. Press the button "lowering". The lift will rise approx. 1 mm (safety function) before it starts to lower.
- Before the lift reaches its lowest position, the lift stops automatically (CE-Stop). After the lift has stopped, check the danger areas around the lift. Press the button "lowering" again. A warning signal will sound as the lift is further lowered. This is to warn against the risk of crushing as the lift is lowered to its lowest (fully collapsed) position.
- Observe the complete lowering process.
- Once the arms are in the lowest position, press the button "unlocking the arms" and remove the arms from under the vehicle.
- Drive the vehicle off the lift.

## 5.3 Position measurement

An hall sensor on the hydraulic cylinder monitors the threaded spindle by counting the magnetised increments on the outer ring.

The number of increments counted is transmitted to the Controller. The controller processes this information and regulates both lifting carriages so that they remain level. The current position is shown on the Display.

- The SST (Safety-Star Technology) observes the complete Process of the Lift during "Lifting" and "Lowering".
- The automotive lift lowers with a average load at a rate of 0.05 Meters per sec. If the lift descends noticeable faster there may be a problem with the hydraulic system. The computer-control-system recognizes the problem and switches off the hydraulic supply for the cylinder. The Safety-star system locks and the lift stops.

## 5.4 Manual equalization of the automotive lift



**Only trained and authorized staff are allowed to work with the DIP-switches! The main-switch must be switched off!**

- If the Computer Control System recognize a difference of approx. 40 mm between both lifting carriages, it will stop the lift automatically.
- Equalize the lifting carriages.
- Open the electrical box.
- Adjust the following Dip-switch as described: (see Pic. Pos. K)
  - Dip switch 5 (regulation ON/OFF).
  - Dip-switch 1 (only lifting carriage 1 moveable).
  - Dip-switch 2 (only lifting carriage 2 moveable).
  - Dip-switch 7 (reset – zero the lift in the lowest position).

### Enforce the equalisation:

- Equalize lifting carriage 1.
- Move the Dip Switch 5 to the "off" position (regulation off).
- Move the Dip switch 1 to the "on" Position (Dip switch 1 for platform 1).
- Press the button "lifting" or "lowering" and the override switch simultaneously until the platform is level.
- Move the Dip switch 1 to the "off" Position.

- Move the Dip switch Dip 5 to the “on” Position (regulation on).
- Press the button “lowering” until the lift reaches the lowest position so that a reset can then be carried out (see chapter “Reset after an emergency lowering”)
- Remount the covers.



Pic 4:

DIP switches

Over ride switch (S6)

## 6. Troubleshooting

If the lift does not work properly, the reason might be quite simple. Please check the lift for the potential reasons mentioned on the following pages. If the cause of trouble still cannot be found, please call technical service.

<b>Problem: Motor does not start!</b>	
<p>Potential causes:</p> <ul style="list-style-type: none"> <li><i>No power supply</i></li> <li><i>Main switch is not engaged</i></li> <li><i>The main switch is defective</i></li> <li><i>Fuse defective</i></li> <li><i>The feed line is cut</i></li> <li><i>Thermal switch in the motor is active</i></li> <li><i>The lifting carriages are not within the control limits (window)</i></li> <li><i>Motor is defective</i></li> </ul>	<p>solution:</p> <ul style="list-style-type: none"> <li><i>Check the power supply</i></li> <li><i>Check the main switch</i></li> <li><i>Check the main switch</i></li> <li><i>Check Fuse</i></li> <li><i>Check the complete cable</i></li> <li><i>Let motor cool down</i></li> <li><i>Read chapter 5.3</i></li> <li><i>Call technical service</i></li> </ul>
<b>Problem: Motor starts, lift does not lift!</b>	
<p>Potential causes:</p> <ul style="list-style-type: none"> <li><i>The vehicle is too heavy</i></li> <li><i>Level of the oil is too low</i></li> <li><i>The emergency lowering screws are not closed</i></li> <li><i>Hydraulic valve is defective</i></li> <li><i>Gear pump is defective</i></li> </ul>	<p>solution:</p> <ul style="list-style-type: none"> <li><i>unload the vehicle</i></li> <li><i>check the oil level, fill with hydraulic oil as required</i></li> <li><i>Check the emergency lowering screw</i></li> <li><i>Call technical service</i></li> <li><i>Call technical service</i></li> </ul>

**Problem: the lift does not lower!**

Potential causes:  
*An obstacle is restricting the lift from being lowered*  
*Hydraulic valve is defective*  
*Fuse is defective*  
*The SST is locked*  
*Button "lowering" is defective*

solution:  
*(see chapter 6.1)*  
*Call technical service*  
*Check the fuse*  
*Call technical service*  
*Call technical service*

**Problem: the arms do not move**

Potential causes:  
*The unlocking button is defective*  
*Not enough air pressure*  
*Air hose defective*

solution:  
*check the button*  
*check the air pressure*  
*check the air hose*

## 6.1 Lowering onto an obstacle


If the Safety-Star-System recognizes a difference of 40 mm between both lifting carriages it automatically switches off the lift.

### 6.1.1 Remove an obstacle



**Only trained and authorized staff are allowed to work with the DIP-switches! The main-switch must be switched off!**

- Remove the cover of the control box.
- Press the button "Reset" (1) and hold it. (see Pic. 5, "Reset Achskontroller 1")



pic 5: Platine - Controller

- Switch off the main switch and wait 5 sec. Hold the reset button.
- Switch on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Move all the Dip-switches to the “off” position.
- Move the Dip-switch 1 and 2 to the “on” position.
- **Caution:** This procedure can only be done when the lift is **not** at its maximum height.
- Closely observe the vehicle on the lift and its reaction.
- Press the “lifting” button until the obstacle can be removed.
- The side of the lift that is higher must be lowered with the help of the corresponding Dip-switch. (see chapter “Equalisation of the two lifting platforms”).
- After equalizing the runways, a reset must be carried out (see the following points).
- Move all the Dip-switches to the “off” position.
- Move the Dip-switch 5 to the “on” position.
- Press the button “reset” (1) and hold it. (Pic. 2)
- Switch-off the main switch and wait 5 sec. Hold the reset button.
- Switch-on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Press the button “lowering” until the lift (both platforms) is in its lowest position (fully collapsed) and the warning signal stops beeping.
- Move the Dip-switch 7 to the “on” position .
- Keep Dip-switch 5 in the “on” position.
- Press the button “reset” (1) and hold it.
- Switch-off the main switch and wait 5 sec. Hold the reset button.
- Switch-on the main switch and wait 5 sec. Hold the reset button.
- Let go off the reset button.
- Keep Dip-switch 5 in “on” position.
- Move Dip-switch 7 to the “off” position.
- Three diodes should now be see on the computer display board. One additional diode should be blinking at the frequency of approx. 1 sec.
- Raise and lower the automotive lift a few times without a load. Observe the process.
- Remount the covers.

## 6.2 Emergency lowering



***A emergency lowering is an intervention into the controls of the lift and can be done only by experienced expert.***

***The emergency lowering must be carried in this order. Otherwise a malfunction may lead to damage to equipment, injury or even death.***



***Every kind of external leakage must be removed. This is particularly necessary before an emergency lowering.***

***The emergency lowering may only be done by persons who are trained in using the lift.***

Reasons, that may warrant an emergency lowering are; a defect in the electric system or disturbances of the valves, etc.

In case of power-failure or defective valves it is the possible through the use of suitable tools to lower the lift to its lowest position so that the vehicle can be driven off.

## 6.2.1 Emergency lowering procedure

- Switch off the main switch and secure it. (lock it)
- Remove the covers of hydraulic unit.
- Secure the danger area around the lift.



*Pic 6:*

*Loosen and remove the 2 lock nuts with a suitable tool (spanner, wrench) in an anti-clockwise direction. Carry out this process on both columns. (Key 41)*



*Pic 7:*

*The piston rod at the top of the column may be restricted by dirt and grit deposits. Use a solvent and a lubricant (for an example WD40) to loosen and lubricate the connection. Spray the WD40 generously between the piston rod thread and the bore hole (see arrow). The time taken to remove the dirty deposit will depend on the degree of contamination.*



*Pic 8:*

*Loosen the both red locknuts at the hydraulic block. Then loosen the both emergency lowering screws with a suitable tool (size5) maximum 1 turn anticlockwise*

Red lock nuts with  
emergency lowering screw



**Pic 9:**  
Use the extended threaded socket connection and turn clockwise with an appropriate tool (socket wrench size 24, available at your dealer.). Lower the lifting carriage only 5cm – 10 cm. Repeat this process on the next column and continue until the entire lift is in its lowest position. Only lower each side 5 cm-10 cm at a time.  
Repair the defective lift. After this is complete, a “Reset” must be carried out (described in the operating instructions).



**Attention!! Lower the automotive-lift only approx. 5cm – 10 cm at a time.**



**Observe the complete emergency lowering process.**



**Do not work with the lift until the defective parts are changed.**



**Resumption of work can only begin once the lift is deemed to be in perfect condition regarding safety.**

- If the lift has been deemed safe to operate, carry out a reset as described in the operating instructions.

### 6.3 Reset after an emergency lowering



**A reset can only be carried out, if the automotive-lift is in its lowest position (fully collapsed).**



**Access to the DIP-Switch is only possible once the main switch is in the “off” position. Only instructed, authorized technical personnel can carry out the reset.**

- Drive the vehicle off the lift.
- Open the cover of the operating unit.
- Open the electrical box door.
- Press the button “Reset” 1 (see pic.5) and hold it.
- Switch-off the main switch and wait 5 sec while holding the reset button.
- Switch-on the main switch and wait 5 sec while holding the reset button.
- Let go of the reset button
- Press the button “lowering” until both lifting carriages are in their lowest position.
- If necessary repeat steps d) to h) several times to be sure that the lift is in its lowest position.
- Next, move the Dip-switch 7 to the “on” position.
- Keep Dip-switch 5 in the “on” position.
- Repeat the steps d) to h)
- Next, move Dip-switch 7 to the “off” position. Keep Dip-switch 5 in the “on” position.
- Three diodes should now light up on the computer-board. One additional diode should be blinking in the frequency of approx. 1 sec.

- o) Raise and lower the automotive lift a few times without load. Observe the process.
- p) Mount the covers.

## 7. Inspection and Maintenance



**Before conducting maintenance work, preparations must be made to ensure that during maintenance and repair work there is no risk to the safety of people working on or around the lift and also that there is no risk of damage to equipment being used on or around the lift.**

To guarantee the utmost availability and to ensure that the lift remains functional, maintenance work contracts are organised between our clients and their local retailers.

A service must be performed at regular intervals of 3 months through the operator in accordance with following service manual. If the lift is in continuous operation or in a dirty environment, the maintenance rate must be increased.

During daily operation the lift must be closely observed to ensure that it is functioning correctly. In the case of malfunction or leakage the technical service must be informed.

### 7.1 Maintenance plan of the lift



**Before beginning any maintenance work isolate the power supply. Secure the main switch (lock it). Secure the danger area around the automotive lift and secure the lift against unintentional lowering.**

Maintenance plan	Period
Check the condition of the type plate, the short operating instruction and the sticker "capacity.	min. 1x yearly
In case of heavy dirt deposit clean the piston rods of the hydraulic cylinders from deposit. Remove the cover of the lift. If necessary raise the lift to the highest position. Grease the piston rods with a high capacity lipid (approx. 5 g of S2 DIN51503 KE2G of the Renolit Company.	min. 1x yearly
Clean and check the moving parts. Lubricate the moving parts of the lift (hinge bolts, rolls, sliding surfaces). Grease with a multipurpose lipid (example: Auto Top 2000 LTD. Agip).	min. 1x yearly
Check the sliding block of the lifting carriage. In case of wear or damages exchange it. Grease it with a multipurpose fat.	min. 1x yearly
Grease the lubricating nipples of the double joint arms with a multipurpose fat.	min. 1x yearly
Check the hydraulic tubes/hoses for leakage. Check the screw fittings.	min. 1x yearly
Check the oil level. Fill in a clean, high quality oil (32 cst) in the tank.	min. 1x yearly
The hydraulic oil has to be changed at least once a year. To change the oil, lower the lift into the lowest position. Empty the tank and replaced clean oil, approx. 21 litres are needed. A high quality hydraulic oil is recommended, its should be 32 cst. (e.g. HLP 32 LTD. OEST Company)	min. 1x yearly

Use a ATF-Suffix hydraulic-oil (OEST Company ) if the ambient temperature is under 5 degree centigrade. After the fill up, the hydraulic oil must be between the upper and low marking of the oil level gauge.	
Check all welded joints for cracks on the automotive-lift. If any cracks are found on the lift cease use immediately. Switch-off and secure the main switch (lock) and call the service partner.	min. 1x yearly
Damage to external surfaces, must be immediately repaired. If theses repairs are not made immediately, permanent damage to the powder-coated surface may result. Repair and clean damaged areas with an abrasive paper (grain 120). After this is complete, use a suitable paint (observe the RAL Number).	min. 1x yearly
Check the zinc surface and repair it with a suitable tool. Use abrasive paper (grain 280). White rust can result from moisture laying in certain areas for long periods of time. Poor aerating can also result in rust formation. Rust may result from mechanical damage, wear, aggressive sediments (de-icing salt, liquids) or insufficient cleaning. Repair and clean these areas with abrasive paper (grain 280). After this is complete, use a suitable paint (observe the RAL Number).	min. 1x yearly
Check the condition and function of the safety device CE-Stop and the acoustic signal, foot protection, locking system of the lifting arms, rubber pads	daily
Check the Battery of the controller (ASC). The Battery has a working life at normal business between 4 ½ - 5 Years (manufacturers statement). To avoid a permanent data-loss through an empty battery, you must examine the battery of the controller during the regularly maintenance. The measuring can only take place at the controller which was switched-off. The measuring is possible with a commercial tensiometer. Standard voltage approx. 3.2 V (no exchange necessary), but a value under 2.9 V, the controller must be exchanged. Send the controller to the Nußbaum Headquarter. Previously, contact your service partner.	min. 1x yearly
Check the electrical cable, plugs for damages	min. 1x yearly
Check the condition and function of the electrical box, press button, signal lamps and labelling.	min. 1x yearly
Check the condition of the cable channels.	min. 1x yearly
Check the condition of the concrete floor at the dowels.	min. 1x yearly
Check the turning moment of the screws (see the list)	min. 1x yearly

## Turning moment for screws

property class 8.8

	0,10*	0,15**	0,20***
M8	20	25	30
M10	40	50	60
M12	69	87	105
M16	170	220	260
M20	340	430	520
M24	590	740	890

property class 10.9

	0,10*	0,15**	0,20***
M8	30	37	44
M10	59	73	87
M12	100	125	151
M16	250	315	380
M20	490	615	740
M24	840	1050	1250

Drehmomenttabelle 8.8-10.9 E

- \* sliding friction 0,10 for very good surfaces, lubricated
- \*\* sliding friction 0,15 for good surfaces, lubricated oder dry
- \*\*\* sliding friction 0,20 surface black or phosphatized, dry

Pic 10:

## 7.2 How often must the lift be cleaned?

A regular and appropriate maintenance practice will aid the preservation of the lift.

No guarantees can be given when damage (egg rust or fading colour) is the direct result of poor maintenance and cleaning practice.

Regular cleaning of all kinds of dirt is the best protection against wear and the formation of rust and will prolong the life of the lift

- Dirty deposits that can cause rust include:
  - de-icing salt
  - sand, pebble stone, natural soil
  - all types of industrial dust
  - water; also in connection with other environmental influences
  - all types of aggressive deposits
  - constant humidity caused by insufficient ventilation

Obviously this is dependent on the type of work being done with the lift, the degree of cleanliness of the workshop and location of the lift. The degree and amount of dirt is dependent on the season, on the weather conditions and the ventilation of the workshop.

During poor conditions it may be necessary to clean the lift once week, but cleaning once a month will suffice.

Clean the lift and the floor with a non-aggressive and non-abrasive detergent. Use a gentle detergent to clean the parts. Use an standard washing-up liquid and lukewarm water.

- Do not use steam jet cleaners.
- Remove all dirt carefully with a sponge or if necessary with a brush.
- Ensure that no washing-up liquid is left on the lift after cleaning.
- Do not use aggressive means for cleaning the workshop floor and the automotive lift.
- A permanent contact with any kind of liquid is not allowed. Do not use high pressure devices for cleaning the lift.

## 8. Security check

The security check is necessary to guarantee the safety of the lift during use. It has to be performed in the following cases:

1. Before the initial operation, after the first installation.  
**Use the form "First security check before initiation"**
2. In regular intervals after the initial operation, at least annually.  
**Use the form "Regular security check at least annually"**
3. Every time the construction of that particular lift has been changed.  
**Use the form "Extraordinary security check"**




**The first and the regular security check must be performed by a competent person. It is also recommended to carry out a service on the lift at this time.**



**After the construction of the lift has been changed (changing the lifting height or capacity for example) and after serious maintenance works (welding load bearing parts) an extraordinary security check must be performed by an expert.**

This manual contains forms with a schedule for the security checks. Please use the appropriate forms for the security checks. The forms should remain in this manual after they have been filled out. A short description about special safety devices follows.

## 9. Handing over and Initiation



### 9.1 Regulations

- The installation of the lift is performed by trained technicians of the manufacturer or one of its distribution partners. If the operator can provide trained mechanics, he or she can install the lift by him or herself. The installation has to be done according to this regulation.
- Installing the standard-automotive lift in a hazardous location or a washing bay is not allowed..
- Before installation a sufficient foundation must be constructed. If the foundation is already constructed then proof that the foundation conforms to the standard is required.  
A level foundation for the installation is required. The foundations must be based in a frost resistance depth, both outdoors and indoors in a position where the installer believes there is no chance of frost.
- An electrical supply 3~/N+PE, 400 V, 50 Hz must be provided.  
The supply line must be protected with a time-lag fuse T16A (VDE0100 German regulation).  
The minimum diameter amounts to 2.5 mm<sup>2</sup>.
- All cable ducts must be equipped with protective coverings to prevent accidents.

## 9.2 Erection and bolting down the lift

Before the installation of the lift, secure the installation area to prevent access to unauthorised persons. Use devices such as cranes, fork lift trucks and supports to transport the lift and avoid accidents.

- Carefully remove the lift from its wooden crate. Check the lift for damage.
- Position the columns as described in the foundation diagram drawing.
- Connect the power supply to the column (by customer).
- Connect the cables between the columns.
- Check the positions of the columns again.
- Fill tanks, approximately 17 litres of hydraulic oil per tank.
- Bore holes in the foundations so that base plates can be bolted down. Clean the holes with compressed air. Put masonry bolts in and secure. The lift-manufacturer demands Liebig safety masonry bolts or equally good bolts from another manufacturer (with licence). Be sure to observe their regulations (bore hole, torque...). Before bolting, check that the concrete-floor is of quality C20/25. If the entire floor is concrete (there is no surface covering), bolts must be selected according to a floor without a surface covering. If the ground is covered with floor tiles or some other form of surface covering, the bolts must be selected according to the floor with floor-covering.
- Press the button "lifting" observe the rotation of the motor.
- If the automotive-lift does not rise, check the rotation-direction of the motor. Otherwise, change two phase of the power supply. (only with 3 phases)
- Fine adjustment of the lift: If necessary use metal sheets to level out an uneven floor. A continuous contact between the floor and the base plate must be ensured to avoid hollow spaces.
- Tighten the masonry bolts to their specified moments using a torque wrench.



***Each masonry bolt must be tightened to the specified torque. Otherwise the normal function of the lift can not be guaranteed.***

***Observe the regulations of other masonry-bolt manufacturers.***

- If necessary, carry out a reset before the first operation. (see chapter 6.3)
- Raise the lift to a height of about 800 mm.
- Mount the lifting arms.
- Raise and lower the lift several times without a load (vehicle) to the upper and lower limits.
- Check that the safety devices are functioning correctly.
- Raise and lower the lift several times with a vehicle to the upper and lower limits. (see chapter 5.2)
- Check the hydraulic system for leakages.
- Check that the masonry-bolts are correctly torque again.



***In the case of any faults, call the customer service immediately!***

## 9.3 Initiation



***Before the initiation a security check must be carried out. Therefore use the form: First security check.***

If the lift is installed by a competent person, he or she is to perform the security check. If the operator installs the lift by him or herself, he or she must instruct a competent person to perform the security check.

The competent confirms the faultless function of the lift in the installation record and the form for the security check and authorises the use of the lift.



***Please send the completed installation record to the manufacturer after installation.***

## 9.4 Change of lift location

If the place of installation is to be changed, the new place has to be prepared in accordance with the regulations of the first installation. The change should be performed in accordance with the following points:


- Raise the lift to a height of about 1000 mm.
- Remove the cover of the tank.
- Remove the lifting arms.
- Lower the lift to its lowest position.
- Remove the oil from tank.
- Remove all electrical cables between the columns.
- Disconnect the power supply.
- Transport the automotive-lift to its new location
- Install the lift in accordance with chapter 9 "Installation and Initiation".



***Use new masonry-bolts, the used bolts can not be used again.***

***A security check must be performed before reinitiation by a competent person.  
Use form "Regular security check"***


## Masonry-Bolt length without floor pavement or tile surface



Liebig-masonry bolts		
Bolt-type		BM16-25/100/40
Drilling depth	a	200
Min. anchorage depth	b	165
Thickness of concrete	c	260
Diameter of bore	d	25
Thickness of the lift-pieces	e	0-35
Number of bolts		14
Starting torque		115 Nm

**You can use equivalent dowels from another dowel manufacturer (with license) but observe their regulation.**


## Masonry-Bolt length with floor pavement or tile surface



### Liebig-bolts


bolt-type		BM16-25/100/65	BM16-25/100/100
Drilling depth	a	125	125
Min. anchorage depth	b	100	100
Thickness of concrete	c	min.250*	min.250*
Diameter of bore	d	25	25
Thickness of the lift-pieces	e+f	40-65	65-100
Number of bolts		20	20
Starting torque		115Nm	115Nm

**You can use equivalent dowels from another dowel manufacturer (with license) but observe their regulation.**





fischer-Dübel		2.60 HL SST <sup>e</sup>		
Dübel typ of dowel type de cheville		FH 15/50 B	FH 18 x 100/100 B	FH 24/100 B
Bohrtiefe drilling depth Profondeur de l'alésage	t <sub>d</sub>	145	230	255
Mindestverankerungstiefe min.anchorage depth Profondeur minimale d'ancrage	h <sub>ef</sub>	70	100	125
Betonstärke thickness of concrete Epaisseur du béton	c	siehe den aktuellen Fundamentplan see current foundation-diagram drawing vois le plan de fondation actuel		
Bohrerdurchmesser diameter of bore Diamètre de l'alésage	d <sub>o</sub>	15	18	24
Bauteildicke thickness of the lift-piece Epaisseur de la pièce	t <sub>fix</sub>	0-50	0-100	0-100
Anzugsdrehmoment Nm turning moment moment d'une force	M <sub>d</sub>	40	80	120
Stückzahl piece number nombre des pièces	a	4		
	b	8		
	c	10		
	d	12		
	e	14		
	f	16		
	g	20		

### Montage




Es können auch gleichwertige Sicherheitsdübel anderer Hersteller (mit Zulassung) unter Beachtung deren Bestimmungen verwendet werden.  
It is possible to use equivalent safety-dowels (with license) of other manufacturer but observe their regulations.  
Des chevilles des autres marques (autorisées) peuvent aussi être choisies en respectant les directives du fabricant.




Änderungen vorbehalten!  
subject to alterations!  
sous réserve des modifications!

Hilti-Dübel					2.60 HL SST <sup>°</sup>	2.60 HL SST <sup>°</sup>
		ohne Bodenbelag	ohne Bodenbelag	mit Bodenbelag	ohne Bodenbelag	mit Bodenbelag
Bodenbelag (Estrich, Fliesen)						
Dübel typ of dowel type de cheville		HSL-3-G M10/40 Art.Nr.371797	HSL-3-G M12/50 Art.Nr.371800	HSL-3-G M12/100 Art.Nr.371831	HSL-3-G M16/50 Art.Nr.371803	HSL-3-G M16/100 Art.Nr.371832
Bohrtiefe drilling depth Profondeur de l'alsage	h <sub>1</sub>	90	105	105	125	125
Mindestverankerungstiefe min.anchorage depth Profondeur minimale d'ancrage	h <sub>ef</sub>	70	80	80	100	100
Betonstärke thickness of concrete Epaisseur du béton	c	siehe den aktuellen Fundamentplan see current foundation-diagram drawing vois le plan de fondation actuel				
Bohrerdurchmesser diameter of bore Diamètre de l'alsage	do	15	18	18	24	24
Bauteildicke thickness of the lift-piece Epaisseur de la pièce	t <sub>fix</sub>	0-40	0-50	0-100	0-50	0-100
Anzugsdrehmoment Nm turning moment moment d'une force	T <sub>inst</sub>	35	60	60	80	80
Gesamtlänge Total length Longueur totale	l	135	164	214	188	238
Gewinde Thread fil	M	10	12	12	16	16
Stückzahl piece number nombre des pièces	a	4				
	b	8				
	c	10				
	d	12				
	e	14				
	f	16				
	g	20				



Es können auch gleichwertige Sicherheitsdübel anderer Hersteller (mit Zulassung) unter Beachtung deren Bestimmungen verwendet werden.  
It is possible to use equivalent safety-dowels (with license) of other manufacturer but observe their regulations.  
Des chevilles des autres marques (autorisées) peuvent aussi être choisies en respectant les directives du fabricant.



Änderungen vorbehalten!  
subject to alterations!  
sous réserve des modifications!

Hilti-Injections dowel		HL 2.60 SST <sup>e</sup>		
Betonboden / concrete floor		ohne Bodenbelag / without floor pavement (tiles)		
Dübel type of dowel type de cheville		HIT-V-5.8 M10x130	HIT-V-5.8 M12x150 Art.Nr.387061	HIT-V-5.8 M16x200 Art.Nr.956437
Bohrtiefe (mm) drilling depth Profondeur de l'alésage	<b>h<sub>o</sub></b>	90	108	144
Mindestverankerungstiefe (mm) min.anchorage depth Profondeur minimale d'ancrage	<b>h<sub>ef</sub></b>	90	108	144
Betonstärke (mm) thickness of concrete Epaisseur du béton	<b>H<sub>min</sub></b>	min.120	min.138	min.180
Bohrerdurchmesser (mm) diameter of bore Diamètre de l'alésage	<b>d<sub>o</sub></b>	12	14	18
Bauteildicke (mm) thickness of the lift-piece Epaisseur de la pièce	<b>t<sub>fix</sub></b>	max.17	max.19	23
Anzugsdrehmoment (Nm) turning moment moment d'une force	<b>T<sub>inst</sub></b>	20	40	80
Gesamtlänge (mm) Total length Longueur totale	<b>l</b>	130	150	200
Gewinde Thread fil	<b>M</b>	10	12	16
Stückzahl piece number nombre des pièces	a	4		
	b	8		
	c	10		
	d	12		
	e	14		
	f	16		
	g	28		
<p>Die Montageanweisung des Dübelherstellers ist Folge zu leisten. Bei Bodenbelag (Estrich/Fliesen) sind längere Dübel zu verwenden.</p> <p>Observe necessarily the installation description of the dowel manufacturer. Use longer dowels with version with floor pavement and tiles</p>				
<p>Es können auch gleichwertige Injektionsdübel anderer Hersteller (mit Zulassung) unter Beachtung deren Bestimmungen verwendet werden. It is possible to use equivalent injections dowels (with license) of other manufacturer but observe their regulations. Des chevilles des autres marques (autorisées) peuvent aussi être choisies en respectant les directives du fabricant.</p>				

## First security check before installation



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	verification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	veri- fication	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	ver-ification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)



## Regular security check and Maintenance



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	ver-ification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	ver-ification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	ver-ification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	ver-ification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Regular security check and Maintenance

 Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	ver-ification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator

If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Extraordinary security check



Complete and leave in this manual

Serial-number: \_\_\_\_\_

kind of check	all right	defect missing	ver-ification	remark
Type plate.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Short operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Warning designation.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Sticker "max. capacity".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button lifting/lowering.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Detailed operating instruction.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition concrete.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Safety device of hinge bolt.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function button "equalization of the lift".....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition automotive lift.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition colour.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Construction (deformation, cracking) .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Torque of the dowels (bolts).....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
torque moments of the screws and dowels.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition operating unit.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition surface piston rod .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition coverings.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition electrical wires .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Level of hydraulic oil .....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Closeness of the hydraulic system.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition hydraulic hoses.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function test with vehicle.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function safety devices.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition welding.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function/condition lifting carriage.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function locking system of the lifting arms.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition rubber pad.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Condition columns.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function CE-Stop.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....
Function acoustic warning signal.....	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	.....

**( mark here applicable, in case of verification mark in addition to the first mark!)**

Security check carried out:.....

Carried out the company:.....

Name, address of the competent:.....

Result of the Check:

- Initiation not permitted, verification necessary
- Initiation possible, repair failures until.....
- No failings, Initiation possible

.....  
signature of the expert

.....  
signature of the operator


If failures must be repaired:

Failures repaired at: .....

.....  
signature of the operator

(Use another form for verification!)

## Hydraulic diagram drawing




## Hydraulic parts list

No.	Description		Order No.
0.1	Oil tank		260HL01520
0.2	Oil filter		980012
0.3	Gear pump 5,8cm <sup>3</sup>	1BK7S9,2Q	982031
0.4	Sub oil motor		992463
0.5	Oil level gauge		980098
0.6	Hydraulic valve		980166
0.7	Hydraulic block		99-572-00-01-5
DB1	Pressure relief valve		155211
DB2	Pressure relief valve		155211
M1-M4	Measuring connection		118495
VW1	Proportional valve	WEP06DA01B0240S	154370
VW2	Proportional valve	WEP06DA01B0240S	154370
VW3	4/2 way valve	WE06DA77A0240F	600394
V1	Holding valve		158503
N1	Emergency lowering screw		120026
N2	Emergency lowering screw		120026
SV1	Double seat valve		158641
SV2	Double seat valve		158641
1.0/2.0	Cylinder + unlocking cylinder		260HL22001

## Electrical diagram drawing

0	1	2	3	4	5	6	7	8	9
---	---	---	---	---	---	---	---	---	---



**SCHALTPLAN**

**Nussbaum Hebetchnik**  
 GmbH & Co. KG  
 Korker Straße 24  
 D-77694 Kehl Bodersweier  
 Tel.: +49(0)7853/899-0

**OBJEKT** : 2.60 HL SST  
**ANLAGE** :  
**KUNDE** :  
**SCHALTPLANNR:** 2.60 HL SST 12/09/001

**1.) Schaltpläne und Schaltunterlagen**

Schaltpläne werden von uns nach bestem Geissen angefertigt. Für bestellte Schaltpläne und Schaltunterlagen werden wir Sie über den Stand der Angelegenheiten im laufenden Betrieb informieren. Bitte beachten Sie, dass die Schaltpläne nur für den Einsatz im Rahmen unserer Gewährleistung bei der Inbetriebnahme bestimmt sind. Nachbestellungen einschließlich der Berechnung von Schaltplänen bei nicht von uns im Betrieb genehmigten Schaltanlagen werden deshalb nur gegen Berechnung gemäß unseren Service-Bedingungen ausgeführt. Kosten für Nachbesserungen durch Dritte können wir nicht anerkennen.

**3.) Sicherheitsprüfung und Schutzmaßnahmen**

Die Schaltpläne werden unter Beachtung der anerkannten Regeln der Technik nach VDE 0100/5.73 (Teil 1) gefertigt bzw. errichtet und geprüft. Folgende Prüfungen wurden durchgeführt:

1. Prüfung der Durchdringung des Schaltchrankes nach VDE 0100/5.73 nach VDE 0100/7.75 Par. 22.
2. Schutzanforderung und Schutzklasse nach VDE 560/11.87.
3. Schutz gegen direktes Berühren nach VDE 0100/5.73 Par. 4.
4. Schutz bei indirektem Berühren nach VDE 0100/5.73 Par. 5.

**2.) Funktionsprüfung der Schaltanlagen**

Schaltpläne sind keine Serienzeugnisse. Bei der Prüfung des Schaltchrankes im Werk können Fehler wie Fühler, Thermistoren und Motoren nicht einbezogen werden. Auch bei sorgfältiger Prüfung der Schaltpläne durch uns, sind grundsätzlich Bestandteile unseres Auftrages, Mängel werden im Rahmen unserer Gewährleistung bei der Inbetriebnahme beseitigt. Unsere Mängel-Wafrung übernehmen wir nur, wenn die Schaltpläne von uns im Betrieb genehmigt sind. Nachbestellungen einschließlich der Berechnung von Schaltplänen bei nicht von uns im Betrieb genehmigten Schaltanlagen werden deshalb nur gegen Berechnung gemäß unseren Service-Bedingungen ausgeführt. Kosten für Nachbesserungen durch Dritte können wir nicht anerkennen.

**Erkundung nach örtlichen Vorschriften**

Vor Inbetriebnahme prüfen, ob Motorstrom mit Motorschutzrelais übereinstimmt. Alle Klemmstellen auf Ordnungsgemäße Verbindung und alle Kontaktschrauben auf festen Sitz prüfen.

Vor Inbetriebnahme Verdrahtung und Steuerung auf richtige Funktion überprüfen. Keine Inbetriebnahme von unbefugter Seite vornehmen lassen. Änderungen vorbehalten

**Diese Schaltpläne sind unser geistiges Eigentum. Sie dürfen ohne unsere Genehmigung weder vervielfältigt noch Dritten weitergegeben werden!**

Datum	80E	
Bearb.		
Gepr.	02.08.2010	

2.60 HL SST	
Deckblatt	
	Bl. 1
13 Bl.	

Datum	80E	
Bearb.		
Gepr.	02.08.2010	


2.60 HL SST	
Deckblatt	
	Bl. 1
13 Bl.	


Datum	80E	
Bearb.		
Gepr.	02.08.2010	

2.60 HL SST	
Deckblatt	
	Bl. 1
13 Bl.	













4		6	
Steuerspannung		Steuerspannung	
2.60 HL SST		2.60 HL SST	
Nussbaum Hebe- und Transporttechnik GmbH & Co. KG Kaiserstraße 24 76844 Heilbronn Tel.: +49 (0) 71 41 70 33 50 Fax: +49 (0) 71 41 70 3 70 87		Nussbaum	
Erspr.		Erspr.	
Ers. F.		Ers. d.	
Datum		Datum	
Bearb.		Bearb.	
Gepr.		Gepr.	
Name		Name	
Datum		Datum	
80E		80E	
02.08.2010		02.08.2010	
13 B1		13 B1	





6		8	
Datum	80E	2.60 HL SST	
Bearb.	02.08.2010	Nussbaum Hebe-technik GmbH & Co. KG Kaiserstraße 24 76844 Heilbronn - Badisches Tel.: +49(0)7143/93350 Fax: +49(0)7143/93387	
Gepr.		Erspr. Erspr. d. Erspr. d.	
Name		Ventile	
Datum		Bl. 7	
		13 Bl.	



0	1	2	3	4	5	6	7	8	9
									
8									10
	Datum	80E						-	
	Bearb.	02.08.2010						+	
	Gepr.								
	Name								
	Datum								
	Urspr.								
	Ers. f.								
	Ers. d.								
					Nussbaum Hebe-Technik GmbH & Co. KG - Kehler Straße 24 - 76844 Heilbronn - Badisches - Tel.: +49 (0) 71 43 93 93 50 Fax: +49 (0) 71 43 93 93 77				
						2.60 HL SST			
								frei	
								Bl. 13 Bl.	



0	1	2	3	4	5	6	7	8	9	
Klemmenplan										
MWRK020 / 22.04.1998										
Leistungsbezeichnung  X1.1	Seite/Pfad	5, 7	5, 7	5, 7	5, 7	5, 7	5, 7	5, 7	5, 7	
	Defizit	1	2	3	4	5	6	7	8	
	Kabelname									
	Kabeltyp									
	Anschluß	X1 1	X1 2	X1 3	X1 4	X1 5	X1 6	X1 7	X1 8	X1 9
	Zielbezeichnung									
	Klemmen-Symbol									
	Brücken									
	Klemmennummer	1	2	3	4	5	6	7	8	9
	Anschluß	SN1 21	SN1 22	SN1 23	SN1 24	SN1 25	SN1 26	SN1 27	SN1 28	SN1 29
Zielbezeichnung										
Kabeltyp										
Funktionstext										
Heizteil Rechtscontroller										
Gegenseite										
-										
+										
12										
2.60 HL SST										
X1.1										
B1 11										
13 B1										
Ers. d.										
Ers. f.										
Ursp.										
Datum 22.12.2009										
Bearb. 80E										
Gepr. 02.08.2010										
Name										
Merk										
Änderung Datum										



Nussbaum Hebe-technik GmbH & Co. KG  
Kaiserstraße 24  
D-76844 Heilbronn  
Tel.: +49 (0) 71 41 93 93 50 Fax: +49 (0) 71 41 93 93 87

0		1		2		3		4		5		6		7		8		9	
Stückliste																			
MUSTECKL 17_01 2003																			
Stückliste																			
Bauteilbenennung	Menge	Bezeichnung				Typen nummer				Lieferant				Artikelnummer					
-R1	1	Motorbleitabdeckung	991312	Nussbaum	991312	Nussbaum	991312	Nussbaum	991312										
-R1	1	Klembreitlichtung	991313	Nussbaum	991313	Nussbaum	991313	Nussbaum	991313										
-R1	1	Klembrett	991314	Nussbaum	991314	Nussbaum	991314	Nussbaum	991314										
R1	1	Rechtscontroller ASC 4000 Vollversion	940260	Nussbaum	940260	Nussbaum	940260	Nussbaum	940260										
R1	1	Federleiste 64pol für Rechtscontroller	FEDERLEISTE 64POL	Nussbaum	FEDERLEISTE 64POL	Nussbaum	FEDERLEISTE 64POL	Nussbaum	FEDERLEISTE 64POL										
R1	1	Leiterkartenhalter / Kartenlasche	120X10029	Zubehör	120X10029	Zubehör	120X10029	Zubehör	120X10029										
R1	1	Befestigungssatz für Leiterartenhalter	120X10059	Zubehör	120X10059	Zubehör	120X10059	Zubehör	120X10059										
R1	1	Blachhalter ASC																	
R1	33	Flachsteckdose 2,8	95265 123 204	RHP	95265 123 204	RHP	95265 123 204	RHP	95265 123 204										
R1	33	Isolierstulle 2,8	F 2,8	RHP	F 2,8	RHP	F 2,8	RHP	F 2,8										
R2	1	Displayrahmen klein . . .komplett	240T5RH21133	Nussbaum	240T5RH21133	Nussbaum	240T5RH21133	Nussbaum	240T5RH21133										
R2	1	Display/kabel Rechtscontroller	DEH16481 5V-LV/L	Nussbaum	DEH16481 5V-LV/L	Nussbaum	DEH16481 5V-LV/L	Nussbaum	DEH16481 5V-LV/L										
R2	1	Display/kabel Rechtscontroller	990874	Nussbaum	990874	Nussbaum	990874	Nussbaum	990874										
B1	1	HALLELEMENTSCHALTER H00-16H5008L 5-55H01/5	H00-16H5008L 5-55H01/5	Nussbaum	H00-16H5008L 5-55H01/5	Nussbaum	H00-16H5008L 5-55H01/5	Nussbaum	H00-16H5008L 5-55H01/5										
B2	1	HALLELEMENTSCHALTER H00-16H5008L 5-55H01/5	H00-16H5008L 5-55H01/5	Nussbaum	H00-16H5008L 5-55H01/5	Nussbaum	H00-16H5008L 5-55H01/5	Nussbaum	H00-16H5008L 5-55H01/5										
F1	1	Sicherungsklemme Trenner 5x20 mm	N4/8 5F	Entreltec	N4/8 5F	Entreltec	N4/8 5F	Entreltec	N4/8 5F										
F1	1	Feinsicherung	FEINSICHERUNG	Entreltec	FEINSICHERUNG	Entreltec	FEINSICHERUNG	Entreltec	FEINSICHERUNG										
F2	1	Sicherungsklemme Trenner 5x20 mm	N4/8 5F	Entreltec	N4/8 5F	Entreltec	N4/8 5F	Entreltec	N4/8 5F										
F2	1	Feinsicherung	FEINSICHERUNG	Entreltec	FEINSICHERUNG	Entreltec	FEINSICHERUNG	Entreltec	FEINSICHERUNG										
F3	1	Sicherungsklemme Trenner 5x20 mm	N4/8 5F	Entreltec	N4/8 5F	Entreltec	N4/8 5F	Entreltec	N4/8 5F										
F3	1	Feinsicherung	FEINSICHERUNG	Entreltec	FEINSICHERUNG	Entreltec	FEINSICHERUNG	Entreltec	FEINSICHERUNG										
G1	1	Schall-Netzgerät Rechtscontroller DC 24 V / 2,5A	560-F24	Lust GmbH	560-F24	Lust GmbH	560-F24	Lust GmbH	560-F24										
H1	1	Digisond akustischer Signalgeber	B/P 228	Deifron Components	B/P 228	Deifron Components	B/P 228	Deifron Components	B/P 228										
-J	1	E-Box mit Montageplatte gelocht 2 xk H0L SST	81045-0017	Krauth technology	81045-0017	Krauth technology	81045-0017	Krauth technology	81045-0017										
-J	1	Montageplatte universal 300x400	81045-0017	Krauth technology	81045-0017	Krauth technology	81045-0017	Krauth technology	81045-0017										
-J	2	Perfect Kabelverschraubung H25x1,5	KABELVERSCHRAUBUNG H25x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H25x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H25x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H25x1,5										
-J	2	Perfect Kabelverschraubung H25x1,5	KABELVERSCHRAUBUNG H25x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H25x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H25x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H25x1,5										
-J	3	Perfect Kabelverschraubung H20x1,5	KABELVERSCHRAUBUNG H20x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H20x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H20x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H20x1,5										
-J	3	Sechskannmutter H20x1,5	SECHSKANNMUTTER H20x1,5	Jacob GmbH	SECHSKANNMUTTER H20x1,5	Jacob GmbH	SECHSKANNMUTTER H20x1,5	Jacob GmbH	SECHSKANNMUTTER H20x1,5										
-J	2	Perfect Kabelverschraubung H16x1,5	KABELVERSCHRAUBUNG H16x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H16x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H16x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H16x1,5										
-J	2	Sechskannmutter H20x1,5	SECHSKANNMUTTER H20x1,5	Jacob GmbH	SECHSKANNMUTTER H20x1,5	Jacob GmbH	SECHSKANNMUTTER H20x1,5	Jacob GmbH	SECHSKANNMUTTER H20x1,5										
-J	2	Perfect Kabelverschraubung H16x1,5	KABELVERSCHRAUBUNG H16x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H16x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H16x1,5	Jacob GmbH	KABELVERSCHRAUBUNG H16x1,5										
-J	2	Sechskannmutter H16x1,5	SECHSKANNMUTTER H16x1,5	Jacob GmbH	SECHSKANNMUTTER H16x1,5	Jacob GmbH	SECHSKANNMUTTER H16x1,5	Jacob GmbH	SECHSKANNMUTTER H16x1,5										
K2	1	INDUSTRIERELAIS 24V 4 Wechsler	2741	BTR	2741	BTR	2741	BTR	2741										
K2	1	Industrierelaiswechsel für 4 Wechsler	110178	BTR	110178	BTR	110178	BTR	110178										
KL1	1	Leistungsschutz 5,7 kWh 24 V DC	116612 01 D 24V DC	Lovato electric	116612 01 D 24V DC	Lovato electric	116612 01 D 24V DC	Lovato electric	116612 01 D 24V DC										
-M1	1	Unterölmotor 1,5 kWh	0074551-506 T	Hanning GmbH	0074551-506 T	Hanning GmbH	0074551-506 T	Hanning GmbH	0074551-506 T										
S1	1	Hauptsch. Not-Bus 3P 16A 5,2kV	R 107/3 0200-EV/50	Hers GmbH	R 107/3 0200-EV/50	Hers GmbH	R 107/3 0200-EV/50	Hers GmbH	R 107/3 0200-EV/50										
S1	1	Druckplatte Flach o. Tast. Platte (H22)	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X										
S1	1	Tastplatte Pfahl (H22)	H22-XD-S-X7	Hoeller	H22-XD-S-X7	Hoeller	H22-XD-S-X7	Hoeller	H22-XD-S-X7										
S1	1	Kontakblock IS 10 (H22)	H22-RK11	Hoeller	H22-RK11	Hoeller	H22-RK11	Hoeller	H22-RK11										
S1	1	Kontaklement IS (H22)	H22-H10	Hoeller	H22-H10	Hoeller	H22-H10	Hoeller	H22-H10										
S2	1	Druckplatte Flach o. Tast. Platte (H22)	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X										
S2	1	Tastplatte Pfahl (H22)	H22-XD-S-X7	Hoeller	H22-XD-S-X7	Hoeller	H22-XD-S-X7	Hoeller	H22-XD-S-X7										
S2	1	Kontakblock IS 10 (H22)	H22-RK11	Hoeller	H22-RK11	Hoeller	H22-RK11	Hoeller	H22-RK11										
S2	1	Kontaklement IS (H22)	H22-H10	Hoeller	H22-H10	Hoeller	H22-H10	Hoeller	H22-H10										
S3	1	Druckplatte Flach o. Tast. Platte (H22)	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X										
S3	1	Kontakblock IS (H22)	H22-RK10	Hoeller	H22-RK10	Hoeller	H22-RK10	Hoeller	H22-RK10										
S3	1	Kontaklement IS (H22)	H22-H10	Hoeller	H22-H10	Hoeller	H22-H10	Hoeller	H22-H10										
S4	1	Starr I (H22)	H22-XD-G-X1	Hoeller	H22-XD-G-X1	Hoeller	H22-XD-G-X1	Hoeller	H22-XD-G-X1										
S4	1	Druckplatte Flach o. Tast. Platte (H22)	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X	Hoeller	H22-D-X										
S4	1	Tastplatte Pfahl (H22)	H22-XD-S-X7	Hoeller	H22-XD-S-X7	Hoeller	H22-XD-S-X7	Hoeller	H22-XD-S-X7										

11

13

Datum		02.08.2010		Nussbaum Hebe-technik GmbH & Co. KG		2.60 HL SST		-		Bl.		12	
Bearb.		80E		Kaiserstraße 24				+		Bl.		13 Bl	
Gepr.		02.08.2010		D-76844 Heilbronn - Badensche Str.						Stückliste			
Änderung		Datum		Name		Urspr.		Ers. F.		Ers. d.			

MUSTECK 17\_01 2003

## Stückliste

0	1	2	3	4	5	6	7	8	9
Bauteilbenennung	Menge	Bezeichnung			Typen nummer	Lieferant	Artikelnummer		
54	1	Kontaktblock 15 10 (H22)			M22-RK11	Hoeller	990132		
54	1	Kontaktlement 15 (H22)			M22-H10	Hoeller	990133		
55	1	Druckkaste Flach o. Tast. Platte (H22)			M22-D-X	Hoeller	990130		
55	1	Tastplatte Pfeil (H22)			M22-KD-S-X7	Hoeller	990131		
55	1	Kontaktblock 15 10 (H22)			M22-RK11	Hoeller	990132		
55	1	Kontaktlement 15 (H22)			M22-H10	Hoeller	990133		
56	1	Drucktaster Einbau Klein 15			05F 131	05ER GmbH	990366		
5H1	1	Kontaktlement 10 (H22)			M22-H01	Hoeller	990181		
5H1	1	NOT-AUS-Taster rot (H22)			M22-PV	Hoeller	990415		
5H1	1	Befestigungsadapter (H22)			M22-H	Hoeller	990265		
5H1	1	Unterlegschild NOT - AUS gelb quadr.			M22-KYK	Hoeller	992387		
T1	1	Trafo + Gleichrichter + Kondensator			TRF02 1-FH	Schmelzer	990835		
V1	1	Sperrdiode BYV 28 - 100			BYV 28 - 100	Conrad Elektronik	940042		
H6	1	Steuerleitung mit num. Rdern (761,0mm <sup>2</sup> )			PVC-STEUERLEITUNG FLEX	Kabel-Hächter GmbH & Co. KG	990282		
H6	1	Steuerleitung mit num. Rdern (761,0mm <sup>2</sup> )			PVC-STEUERLEITUNG FLY	Kabel-Hächter GmbH & Co. KG	991104		
HV	1	Steuerleitung mit num. Rdern (12x1,0)			PVC-STEUERLEITUNG FLEX	Kabel-Hächter GmbH & Co. KG	990079		
HV	1	Steuerleitung mit num. Rdern (12x1,0)			PVC-STEUERLEITUNG FLEX	Kabel-Hächter GmbH & Co. KG	990466		
X1	4	Schutzleiterk1 0 4/6 P. R00 schraub-schn			0 4/6 P. R00	Entrelec	990767		
X1	9	Reihenleiste 0P 4/6 R00 grau schraub-schn			0 4/6 R00	Entrelec	990761		
X1	1	Schutzleiterk1 0 2,5/6 P. R00 schn-schn			0 2,5/6 P. R00	Entrelec	990185		
X1	1	Abschlussplatte 3 mm grau. für DJ. 5/6 ... R00			ABSCHLUSSPLATTE FER02	Entrelec	990582		
X1	1	Bezeichnungskarte L1-L2-L3-RE horizontal			RC05 6X5 L1-L2-L3-H-PE	Entrelec	990732		
X1	1	Bezeichnungskarte 1-10 horizontal			RC05 6X5 1-10	Entrelec	990743		
X1 1	5	Reihenleiste 0P 4/6 R00 grau schraub-schn			0 4/6 R00	Entrelec	990761		
X3	1	Steckverb. Gerüststecker ku 6 pol.			STECKVERBINDER	R5 Component	990918		
X3	1	Steckverb. Gerüststecker ku 6 pol.			STECKVERBINDER	R5 Component	990918		
X3	0	Stiftleinsatz für Gerüststecker			STIFTEINSATZ	Sporte GmbH	990212		
X3	0	Buchseninsatz für Gerüststecker			BUCHSENEINSATZ	Sporte GmbH	991330		
X4	1	Steckverb. Gerüststecker ku 6 pol.			STECKVERBINDER	R5 Component	990918		
X4	1	Steckverb. Gerüststecker ku 6 pol.			STECKVERBINDER	R5 Component	990918		
X4	0	Stiftleinsatz für Gerüststecker			STIFTEINSATZ	Sporte GmbH	991330		
X4	0	Stiftleinsatz für Gerüststecker			STIFTEINSATZ	Sporte GmbH	991331		
YH1	1	Ventilstecker			GERÄTESTECKER	Seehausen	980654		
YH1	1	Ventilstecker			GERÄTESTECKER	Seehausen	980654		
YH1	1	Ventilstecker			GERÄTESTECKER	Seehausen	980654		
YH1	1	Ventilstecker			GERÄTESTECKER	Seehausen	980654		
YH1	1	Sperrdiode 1M40007 1000V; 1A			1 M 40007	Conrad Elektronik	990652		
YH1	1	Sperrdiode 1M40007 1000V; 1A			1 M 40007	Conrad Elektronik	990652		
YH1	1	Sperrdiode 1M40007 1000V; 1A			1 M 40007	Conrad Elektronik	990652		
YH1	1	Sperrdiode 1M40007 1000V; 1A			1 M 40007	Conrad Elektronik	990652		

12

Datum	02.08.2010	Nussbaum Hebe-technik GmbH & Co. KG		2.60 HL SST		-	
Bearb.	80E	Kaiser Straße 24				+	
Gepr.	02.08.2010	D-76844 Heilbronn - Baden-Württemberg					
Änderung		Datum		Name		Menge	
		Urspr.		Ers. F.		Ers. d.	
						Stückliste	
						Bl. 13	
						13 Bl.	